

# **Growlrr Foods**

Pilot Binder

Revision H.3.1.1

Date: 26-10-2025, Chennai, India

*Formulations and Standard Operating Procedure for Pilot Run*

Property of Growlrr Foods Pvt Ltd

Confidential and Proprietary - Not for circulation

Internal R&D use only- Not for sale or distribution

Contact Information: <https://www.growlrr.com>

# Contents

# List of Tables

# Abstract

---

Growlrr Foods pioneers the future of pet nutrition with biologically appropriate, human-grade balanced and complete meals built on evolutionary science and rigorous safety systems. Our structured rotation model delivers balance, variety, and long-term vitality while preserving the simplicity pet parents need, while every formulation is regulatory compliant with AAFCO and FEDIAF standards. Our interlocking products are designed with a systems approach, formulated from first principles, engineered with modularity, anchored by compliance discipline, validated by clinical nutritionists, tested in accredited labs, and finally approved by the only ones that matter: cats and dogs themselves.

---

# Preface

This binder describes the Growlrr pilot formulations, standard operating procedures for building the product, bill of materials, incoming and outgoing QC, regulatory framework, nutritional audits for formulation and appendices. Values are design assumptions for pilot runs and are intended to be validated by finished-product assays. Standards and raw-ingredient data are cited in the bibliography. All SKUs meet baseline nutrient standards for labeling.

The present pilot study has been designed as a **60 kg retort validation run** with **6 distinct recipes 10 kg each**, retort stabilised and packed into standardized **100 g pouches**. We deliberately use **pouches rather than cans** at this stage, since pouch retort facilities are cost-accessible, and they provide sufficient resolution to measure our primary objectives. The learnings from pouches are fully translatable to cans for subsequent scale-up.

## Objectives of the Pilot Run

1. **Nutrient assays:** Verify macro- and micro-nutrient retention post-retort against AAFCO/FEDIAF floors and ceilings.
2. **Shelf-life testing:** Establish accelerated shelf life values with rancidity, oxidation, and microbial profiles.
3. **Structural integrity:** Assess gel matrix stability, phase separation, and form factor.
4. **Palatability:** Track voluntary intake, preference, and tolerance in animals across SKUs.
5. **Ingredient validation:** Confirm that each SKU's ingredient design performs as expected under thermal processing.
6. **Process validation:** Confirm reproducibility of SOP steps (solid prep, blanch, liquid assembly, premix dosing, sealing, retort profile).
7. **Sub-optimisation testing:** Fine-tune gel matrix, chelators, palatants, tocopherol distribution, and retort curve.
8. **Credibility:** Generate assay-backed evidence that Growlrr's rotation logic, premix dosing, and paired-SKU genome strategy are regulator-ready and consumer-safe.

This pilot is therefore not only a technical validation but also a credibility-building exercise. It demonstrates the safety, stability, and innovation of Growlrr's formulations under real-world processing conditions, bridging design assumptions to empirical data.

# Executive Summary

Growlrr Foods is a pet nutrition start-up pioneering a new standard in companion animal feeding: human-grade, biologically aligned, rotation-based meals delivered in retort pouches. By applying evolutionary nutrition science, rigorous formulation, and food-safety systems from human FMCG, Growlrr delivers meals that are simultaneously safe, compliant, and innovative.

The model is revolutionary in three ways. First, it positions whole-protein organ blends and fish as the nutritional core, respecting the biology of obligate carnivores. Second, it introduces a structured **rotation system** across multiple SKUs, ensuring balanced micronutrient intake, reduced dietary monotony, and better long-term health outcomes. Third, it uses **human-grade sourcing and processing**: retort sterilisation for ambient safety, alginate-stabilised broth for texture and nutrient stability, and premix formulations designed to meet regulatory nutrient floors without dangerous excesses.

Growlrr is innovative yet safe. Innovative because it proves pet food can be designed as a system, not just a flavour choice, and shows that transparency and whole-food integrity can scale commercially. Safe because every formulation is locked by SOPs, nutrient budgets, and conservative safety margins, ensuring compliance with FEDIAF/AAFCO standards while respecting vitamin A limits, retort stability, and trace mineral balance.

What makes Growlrr unique is this fusion of **science, care, and operational discipline**. It doesn't just promise "better food" — it gives pet parents confidence that every meal is worthy of the bond they share with their animals. The rotation system turns feeding into a rhythm of health and variety, ensuring pets thrive while their owners feel assured they are doing right by them.

Growlrr Foods is more than a brand; it is the **future of companion animal nutrition** — human-grade, scientifically precise, and emotionally resonant. It addresses today's frustrations while setting tomorrow's standard, with defensibility built on proprietary feeding methodology, robust formulation IP, and a transparent brand promise that redefines trust in the category.

# Chapter 1

## Why Growlrr Exists

### 1.1 The Problem with “Complete & Balanced”

Humans and wild predators — including the ancestors of our household cats and dogs — thrive on dietary variety. In nature, no two meals are identical; there is a cadence to days, seasons, and life stages across every species’ lifetime.

Now imagine this: as a human, you are required to eat finely milled corn and soy sprayed with emulsified fat, fortified with a pharmacist’s list of minerals, vitamins, and amino acids — every day, three meals a day, for the rest of your life, because it is labelled “*Complete & Balanced*.”

Sure, you would survive. But would you *thrive*? Would you feel alive, or simply *fed*?

Or imagine being served a boiled gruel of discarded bird carcasses — bones intact — topped with pharmaceutical additives and labeled “*Atlantic Salmon Extracts*” despite containing only traces. Would you find joy in that? Would you reach your full potential, or merely avoid starvation while accumulating hidden deficiencies, obesity, kidney disease, and chronic inflammation?

This is precisely what the modern pet food industry offers our companions: survival dressed up in shiny packaging and backed by targeted advertising. What cannot be packed into the bag is sold separately through an exploding supplements market — proof that the base diet is fundamentally inadequate.

#### The Inconvenient Truth

“Complete & Balanced” sounds authoritative. But the uncomfortable truth is this: *complete by what standards, and balanced by whose measure?*[\[ref64\]](#)

For over half a century, companion animal nutrition has been dictated not by independent science, but by industry lobbies — chief among them the **Pet Food Institute**[\[ref71\]](#), the trade arm of multinational kibble conglomerates. These same corporations, implicated in climate change, water pollution, and global ecological destruction, sit alongside regulators to shape definitions that protect profit margins through cheap fillers and mass-produced chemicals.

Meanwhile, in Europe and North America, nutritional guidelines were drafted by committees dominated by these same conglomerates. The standards trace their lineage not to predator biology, but to **livestock feed protocols** — guidelines written for cattle, poultry, and animals destined for slaughter[\[ref70\]](#), not for companions meant to thrive across decades of life.

The bar was set at mere survival, not vitality[\[ref59\]](#). Chronic diseases — kidney failure, obesity, diabetes, cancer — were never part of the compliance equation[\[ref41\]](#). What should have been shaped by good faith science was instead skewed by supply-chain logistics and profit maximization.

The result: a half-century of lobbying, subsidies, and papered-over standards[\[ref71\]](#) — an agro-industrial legacy borrowed wholesale from slaughterhouse feed.

## 1.2 Our Approach

The Growlrr system is built to reflect biology while meeting the discipline of modern science. We did not set out to make another “flavor range” of pet food; we built a nutritional architecture.

At its core, the system is **organ-forward and bone-broth based**. Organs, yolks, and muscle meats are balanced with natural hydration and collagen-rich broth to deliver the nutrients of real prey in their most bioavailable form. This avoids the filler-heavy, starch-padded formulas that dominate conventional products.

Our SKUs are **species-segregated** — poultry, mammal, and fish are kept hermetically separate, never cross-contaminated. This mirrors natural feeding lanes, reduces the risk of allergen over-exposure, and preserves the diversity of amino acids across species. The SKUs are not random flavors: they are color-coded units designed to fit together like a puzzle. Each pouch is compliant on its own, but when paired daily and rotated weekly, they complete the whole-prey model, ensuring both safety and resilience.

We use **precision premixes** — CatPro, DogPro, and Pluto calcium — only where reinforcement is essential. Heat-labile nutrients, trace minerals, or regulatory minima are addressed surgically. Supplementation is never a crutch; it is a guardrail. This keeps the food clean, while still guaranteeing compliance.

Sourcing is **human-grade, antibiotic-free, and traceable**. Poultry comes from spent layers raised without antibiotics, fish are chosen for low heavy-metal risk, and every lot is matched against supplier COAs. This sourcing integrity, combined with minimal-step SOPs and post-retort validation, ensures both nutritional adequacy and consumer trust.

Beyond ingredient quality, Growlrr’s operational framework prioritizes traceability and reproducibility. Every supplier delivers Certificate of Analysis documentation matched against our specifications for moisture, protein content, heavy metal limits, and microbiological safety. Our standard operating procedures lock in precise sequences—from blanching times for organ meats to retort temperature curves—ensuring that nutritional integrity survives thermal processing. This discipline transforms artisanal quality into scalable manufacturing without sacrificing the whole-food principles that define our approach.

But the real revolution is not only in the pouch — it is in how the food is used. The **Growlrr Web App** generates a customized **rotation diet chart** for every animal, taking into account breed, age, growth stage, activity level, and any veterinary advisories. Owners are guided meal by meal, week by week, with no guesswork. A built-in **Vet Chat feature** allows owners to consult nutritionists, track progress, and adjust feeding as needed, ensuring pets receive age- and size-appropriate nutrition throughout their lives.

The Growlrr system also addresses a fundamental oversight in conventional pet nutrition: the assumption that one formula can serve all life stages and activity levels. Our web application generates individualized feeding plans that account for breed-specific metabolic rates, growth phases in puppies and kittens, reproductive demands, and senior nutritional needs. This personalization, combined with veterinary oversight through our consultation platform, ensures that rotation diversity translates into real-world health outcomes rather than merely checking regulatory boxes.



In short, Growlrr delivers **safety in every pouch, resilience in rotation, and precision in practice** — a system designed not as marketing, but as engineering for biology and care.

## 1.3 Our Values

At Growlrr, we believe the values we hold true will ultimately determine the health and joy of millions of companion animals who depend on us to feed them right. These are our values. They are not flexible. We do not compromise.

### Our Core Principles

- **Safety First.** Every pouch must be nutritious and safe on its own and resilient in rotation.
- **Biology Above Convenience.** Cats and dogs are descendants of predators, not livestock. Their diets must reflect physiology, not the economics of grain or extrusion.
- **Whole Food Integrity.** Organ meats, bone broth, yolks, and hydration form the foundation. Premixes are used sparingly — to reinforce, never to replace.
- **Rotation as Principle.** Variety is structural, not decorative. Rotation prevents monotony, reduces allergen risks, and builds resilience.
- **Transparency Always.** Color-coded SKUs, app-guided diet charts, full traceability. Nothing hidden, from source to shelf.
- **Quality Without Compromise.** Human-grade inputs, antibiotic-free poultry, traceable fish, documented SOPs. Trust is built into process, not added in marketing.
- **Compliance is Baseline.** We meet AAFCO/FEDIAF benchmarks for every pouch. However, since our pouches are strictly species segregated, we use our Growlrr model comprising of color-coded daily SKU pairing and full weekly rotational diet chart customized freely on our website. This way the diversity of nutrition is met from mammal, bird and fish species making it truly “Balanced and Complete.”
- **Engineering Meets Veterinary Science.** Designed with a systems approach, formulated from first principles, engineered with modularity, anchored by compliance discipline, validated by clinical nutritionists, tested in accredited labs, and finally approved by the only ones that matter: cats and dogs themselves.

These values transform every design aspect of Growlrr into an act of trust-building. When we share complete ingredient lists down to the microgram, when we publish our pairing logic and rotation methodology, when we explain why food is nutrition and feeding is love not just a chore. We’re inviting pet parents into a partnership where knowledge replaces blind faith, where understanding breeds confidence, and where every meal becomes a deliberate choice rather than a default compromise. This transparency doesn’t just differentiate Growlrr in the market; it redefines what the market can become. Our values aren’t principles we uphold—they’re the revolution we’re living.

### Time to Redefine

**Variety is the essence of life. Balanced variety is life..** If “Complete & Balanced” is repeated like gospel, yet defined by standards written for slaughter animals and lobbied for profit by Global Conglomerates complicit in ecocide, then it fails our pets and betrays our values. Our animal companions are not livestock. They are descendants of apex predators — mini lions and tigers and wolves who share our homes, our lives, and our love[ref1]. It is time to redefine the standards for those we care for most and for those who depend on us to do the right thing. It is time to **Growl.**

# Chapter 2

## Introduction to CatCore

### Introduction to CatCore

Welcome to the Growlrr universe: a unique, modular, rotational feeding system built on species-appropriate, whole natural ingredients. Each recipe is organ-forward, balanced with muscle and supportive tissues, and carefully fortified to safely meet AAFCO/FEDIAF compliance. There are no grains, no fillers, no gimmicks — only biologically aligned formulations rooted in whole-prey logic, adapted for everyday feeding convenience across all life stages.

### The Six CatCore SKUs

Growlrr's feline system is expressed in six locked SKUs, each a distinct organ-forward recipe. They are paired into bonded “base pairs” using a light–dark color code system, ensuring owners always feed one light + one dark pouch per day. This makes compliance foolproof at the consumer level.

To make this simple for owners, every SKU is **color-coded and named** by its anchor ingredient:

-  Chicken Heart (Light Blue)
-  Sardine (Dark Blue)
-  Chicken Liver (Light Red)
-  Chicken Gizzard (Dark Red)
-  Goat Kidney (Light Brown)
-  Goat Spleen (Dark Brown)

The Growlrr app translates this into daily diet charts — easy to follow at a glance, backed by clinical rigor.

### Example: Meet Bella the Cat (4.0 kg, indoor, adult)

Bella thrives on rotation. Her **weekly chart** is shown in Table 2.1.

Each pouch delivers full compliance; the rotation ensures diversity of proteins, amino acids, and micronutrients, with no monotony.

Each pair balances nutrients in a complementary way: heart and sardine pair balance taurine and phosphorus loads over the day; liver and gizzard pair smoothens out vitamin A and taurine peaks; kidney and spleen are both non-poultry hypoallergenic pairs with mineral rich high quality protines. Individual SKU is designed to meet Ca:P ratio of 1.1 or greater. This “nutritional genome” framework encodes safety into packaging, without owners needing spreadsheets or nutritional degrees.

### Why Rotation?

Why do we design this way, instead of offering one fixed “complete” SKU or a rack of multiple, non-interlocking flavors as most brands do? Because animals do not thrive on monotony, nor on randomized variety. Rotation allows for[[ref3](#), [ref12](#), [web6](#), [web75](#)]:

- Natural smoothing of nutrient peaks and valleys across days.
- Exposure to different organ and muscle profiles, reducing allergen risk[web27, web32, web76, web77, web83] and avoiding chronic overload of any single nutrient.
- Built-in behavioral enrichment — meals taste different, but within a consistent logic that keeps nutrition safe.
- A regulator-ready compliance story: daily safety, weekly completeness, minimal SKU proliferation.

Growlrr’s system is not “flavors.” It is a structured code, a genome of nutrition, where pairs interlock like base-pairs in DNA. The result: biological precision with consumer simplicity. Pet owners can generate their free customized diet chart[ref10] from our website ([www.growlrr.com/diet/](http://www.growlrr.com/diet/)), schedule online chat or call with a pet nutritionist or vet, interact with our trained AI to learn more about each ingredient in our pouch, source, traceability and quality.

Table 2.1: Bella’s Weekly Rotation Chart (4 kg cat, indoor adult)

| Day | Morning (AM) | Evening (PM) |
|-----|--------------|--------------|
| Mon | Heart        | Sardine      |
| Tue | Liver        | Gizzard      |
| Wed | Kidney       | Spleen       |
| Thu | Heart        | Sardine      |
| Fri | Liver        | Gizzard      |
| Sat | Kidney       | Spleen       |
| Sun | Liver        | Gizzard      |


# Chapter 3

## Introduction to DogCore

### From Cats to Dogs — The DogCore Extension

Growlrr's system begins with cats — obligate carnivores, finely tuned to high-protein, organ-forward diets. From this foundation, we extend the same genome logic to dogs, but adapted for their physiology. Dogs are facultative omnivores[ref2]: they can synthesize certain essential nutrients, they tolerate carbohydrates well, and they thrive across a wider range of macronutrient profiles.

### The Golden Mean (DogCore + DogPro)

Instead of proliferating dozens of dog SKUs across breed sizes, Growlrr encodes a single core dog pouch with high quality and highly digestible proteins — **DogCore SKU7**, color-coded  golden orange, designed as the “Golden Mean.” It was engineered to meet the nutritional needs of a Golden Retriever — the prototypical mid-sized dog — and then scales seamlessly up or down for other breeds.

### Why this design?

- **Dense protein base:** DogCore combines soy protein isolate, whey protein concentrate, egg yolk powder, egg white powder and functional lecithin. This leverages both animal and plant proteins, aligned to canine physiology.
- **Omnivore flexibility:** Dogs can derive energy safely from carbohydrate staples. Instead of retorting and shipping grain-heavy fillers, we empower owners to add fresh, digestible staples — cooked rice and probiotic curd/yogurt — from their own kitchens.
- **Balanced micros:** DogPro premix delivers a robust, conservative baseline of vitamins (A, D, E, B-complex) and trace minerals (Ca, Fe, Zn, Cu, Mn, Se, I), ensuring every lane clears AAFCO/FEDIAF floors without drifting into excess.

### Why Not Ship Carbohydrates?

We believe hauling vast quantities of rice or curd through retort packaging, warehousing, and delivery is unnecessary — every pet-owning household already has access to these staples. By leaving energy carriers to the home, Growlrr minimizes shipping weight, maximizes freshness, and keeps costs fair. Instead, our pouches carry the critical load: proteins and micronutrients, precisely balanced to regulatory standards.

### Scaling Across Breeds and Sizes

With CatCore, every 100 g pouch was standardized to  $\approx 100$  kcal. DogCore follows the same unit logic. Scaling across breeds becomes a matter of meals/day and rice+curd quantities:

This modularity means a single DogCore SKU, paired with CatCore and scaled via pantry staples, can safely feed a 4 kg cat or a 40 kg bulldog — without exploding SKU counts or compromising nutrient safety.

**Example: Ringo the Golden Retriever (28 kg, active adult)**

Meet Ringo, a healthy and happy Growlrr who follows his diet chart and enjoys his 3 meals per day . Ringo follows his breed appropriate **DogCore lane** (see overleaf), paired with fresh pantry staples available at home. Each meal = 1 Catcore pouch + 1 DogCore pouch + Fresh Curd rice (250g) + 20g boiled vegetable. See Table 3.1.

Table 3.1: Ringo’s Daily Dog Bowl (per sitting)

| Day | AM                                  | PM                                    |
|-----|-------------------------------------|---------------------------------------|
| Mon | Chicken Heart + DogCore + Curd Rice | Sardine + DogCore + Curd Rice         |
| Tue | Chicken Liver + DogCore + Curd Rice | Chicken Gizzard + DogCore + Curd Rice |
| Wed | Goat Kidney + DogCore + Curd Rice   | Goat Spleen + DogCore + Curd Rice     |

Color Key: CatCore + DogCore + Home staples (curd + rice)

**Feeding Rules**

Growlrr’s modular CatCore + DogCore pairing supplies the full amino acid and micronutrient spectrum. Non-poultry days de-sensitises immune system and reduces allergens Curd rice + veg delivers easily accessible fresh and digestible carbohydrate, calcium, and probiotics. Use fresh or refridgerated 4%-fat whole-milk curd and plain cooked rice. Avoid lentils, spice, salt or butter. Feed as per diet chart with daily pairings and weekly rotation. Ensure constant access to clean water. Consult our Vet on growlrr.com for any prior lactose/dairy allergy or other intolerances.

**Growlrr Dog Feeding Lanes — Canonical Advisory**

Each pouch (100 g) supplies about 120 kcal. Curd + rice mix (150 g rice + 100 g curd ≈ 300 kcal) forms the fresh staple. Feeding pattern scales by body weight and activity.

**In short:** With 6 CatCore SKUs and 1 DogCore SKU, Growlrr encodes a complete nutritional system, scaling safely across species, breeds, sizes, and life stages — delivering physiology-first nutrition with pantry-level practicality.

Table 3.2: Growlrr Dog Feeding Lanes by Breed Size

| Lane         | Breeds                                  | Wt (kg) | kcal /day | Meals | Feeding Advisory per meal                                   |
|--------------|---|---------|-----------|-------|---|
| 1 — Toy/Mini | Chihuahua, Pomeranian, Toy Poodle       | 2–5     | 250–350   | 2     | ½ CatCore + ½ DogCore + 120 g curd-rice + 10 g veg per meal |
| 2 — Small    | Beagle, Cocker Spaniel, French Bull-dog | 6–10    | 400–550   | 2     | 1 CatCore + 1 DogCore + 150 g curd-rice + 15 g veg per meal |
| 3 — Medium   | Indie, Border Collie, Shiba Inu         | 11–20   | 600–900   | 2     | 1 CatCore + 1 DogCore + 200 g curd-rice + 20 g veg per meal |
| 4 — Large    | Labrador, Golden, Boxer                 | 21–35   | 1000–1500 | 3     | 1 CatCore + 1 DogCore + 200 g curd-rice + 20 g veg per meal |
| 5 — X-Large  | Rottweiler, GSD, Husky                  | 36–50   | 1600–2000 | 3     | 1 CatCore + 1 DogCore + 300 g curd-rice + 25 g veg per meal |
| 6 — Giant    | Great Dane, Mastiff, St Bernard         | 50+     | 2200–2800 | 3     | 1 CatCore + 1 DogCore + 350 g curd-rice + 30 g veg per meal |

With easily available kitchen staples like fresh rice, oats, curd, yogurt and vegetables, Growlrr is able to scale from 4.0 Kg cat diet to 40 Kg Rotweiller with just 7 variants and customised diet charts. This is possible because unlike other brands Growlrr does not package and ship carbohydrates and vegetables which are available for cheap in every kitchen. Instead we focus on nutrient rich proteins and organs and precise vitamin and mineral balance and a diet chart that is customised for every animal's dietary needs.

**Approved Vegetable Add-ins for Dogs**

| Boiled vegetable option per meal | Portion (g) | Home Measure            | Notes   |
|----------------------------------|-------------|-------------------------|---|
| Carrot                           | 20          | ¼ medium carrot, cubed  | Beta-carotene                                   |
| Green peas                       | 20          | 2 tbsp, mashed          | Mild protein + fiber                            |
| Zucchini                         | 20          | ¼ cup slices            | Low-oxalate filler                              |
| Spinach / Kale purée             | 20          | 1 heaped tbsp           | Iron + antioxidants —Max once per week          |
| Green beans                      | 20          | 3–4 beans, chopped fine | Safe fiber                                      |
| Sweet potato                     | 20          | 1 tbsp mash             | Slow carbs                                      |
| Pumpkin                          | 20          | 2 tbsp mash             | Gut motility                                    |
| Banana (fruit)                   | 15          | 2–3 slices              | Occasional dessert/treat —<br>Max once per week |

**Feeding Notes**

Pick any one vegetable per meal. Use rotation across meals to avoid monotony. All vegetables are boiled or lightly steamed, unseasoned, and unsalted. Avoid onions, garlic, broccoli, cauliflower, or starchy fillers. Keep total vegetable content near 20g/meal or as noted.

**Growlrr Dairy & Carbohydrate Advisory — EU / US (Oats + Greek yogurt option)**

This adaptation is the Growlrr equivalent of the Indian *curd + rice* staple, tailored for EU / US kitchens where rolled oats and plain cultured Greek yogurt are more common. The objective is identical: provide readily accessible, digestible carbohydrates and live probiotic cultures in addition to Growlrr's protein and nutrient dense packs.

**Handling, Safety & Freshness**

- Use only **pasteurised** Greek Yogurt labelled with live cultures for probiotic benefit. Avoid sweetened, flavoured, or fruit-added products.
- Store cultured dairy at  $\leq 4^{\circ}\text{C}$  (40 °F). Discard if discolored, odour becomes sour, or if abnormal whey separation occurs (large pools of discoloured liquid).
- Boil oats and vegetables together where possible to retain nutrients.
- If using Greek yogurt that is highly s
- Always introduce dairy gradually if new. Watch for signs of lactose intolerance. Consult our vet at [www.growlrr.com](http://www.growlrr.com) if needed.



Table 3.3: EU/US Dairy &amp; Carbohydrate Options

| Component                                | Qty per meal     | Guidance and Notes  |
|--|------------------|---|
| Rolled oats                              | 150 g (or ½ cup) | Cook rolled oats until soft; mix with yogurt while warm   |
| Unsweetened Greek yogurt (live cultures) | 100 g            | Preferred EU/US substitute for full curd. Must be <b>unsweetened, plain, full-fat</b> , and labelled “ <i>live active cultures</i> ” (or equivalent). Greek yogurt is often strained; if texture is extremely thick, add 20–30 ml unsalted buttermilk or water to reach spoonable consistency for mixing. |
| Cultured buttermilk / kefir (backup)     | 100 ml           | Cultured buttermilk or kefir (plain, unsweetened, pasteurised milk origin) are acceptable alternates. Kefir is probiotic-rich but may have stronger flavour; introduce gradually.   |
| Ricotta / cottage cheese (pasteurised)   | 100 g            | Acceptable non-probiotic fallback for short-term when live-culture yogurt is not available. Use plain <b>pasteurised</b> ricotta or low-salt cottage cheese. These supply calcium and proteins but no probiotics.   |
| Plant-based “yogurts” (soy, almond, oat) | —                | Do <b>not</b> use routinely unless under veterinary guidance. They lack animal-based amino acids and deliver different mineral profiles; their use may require compensatory formulation adjustments.  |
| Fat correction                           | —                | If using low-fat yogurt, add ½ teaspoon unsalted butter or ghee per ~250 g mix to restore energy density for active dogs. This helps match the caloric role of whole-milk curd.   |

## Chapter 4

# Formulation Specifications

### Canonical Specification — Growlrr CatCore v5

#### CatCore SKUs 1-6

- All CatCore SKUs follow the canonical format per 100g wet food pouch:
- 65 g wet solids
- 3.0 mg premix packets added to broth as per SOP
- 2.5mg omega-3 fish oil PV<=5 meq/Kg is added to broth phase for omega3:omega6 balance in all SKUs except sardines.
- 1.0mg meat hydrolysant palatant is added to broth phase for umami and flavor.
- 41.5 g  $\pm 0.5$  g broth fill
- Sealed to achieve 112.5 g nominal pre-retort weight. Pre-Fill QC Check.
- Declared 100 g post-retort with  $\approx 10\%$  moisture loss. Post Retort QC Check to 100.5g.

Table 4.1: CatCore Formulation — Heart (H) SKU

| Ingredient             | Mass (g) | Nutrient role and rationale  |
|------------------------|----------|--|
| Chicken Heart          | 24.0     | High taurine and heme iron source for cardiac health and taste; taurine partner for Sardine in PM.   |
| Chicken Muscle Cuts    | 16.0     | High-quality amino acid source forming the protein base.   |
| Chicken Frame Mince    | 15.0     | Provides bone-derived minerals; improves Ca:P ratio; source of condroitin for joint stability        |
| Egg yolk powder        | 4.0      | Choline and fat-soluble vitamins; improves emulsion stability and mouthfeel.                         |
| Pumpkin puree          | 4.0      | Fibre; enhances stool quality and regularity.  |
| Chicken Liver          | 2.0      | Provides vitamin A; limited to prevent excess while complimenting premix micronutrient completeness. |
| <i>Solids subtotal</i> | 65.0     | Fixed solids per pouch.  |
| Chicken Bone Broth     | 41.5     | Broth allocation per pouch pre-retort.   |

### Composition for CatCorePro

#### Composition Notes:

- **CatCore:** Provides high quality muscle, organ, skeletal and fish meat protiens. Primary source of protiens, fats, vitamins, minerals.

Table 4.2: ■ CatCore Formulations — Sardine (S) SKU

| <b>Ingredient</b>  | <b>Mass (g)</b> | <b>Nutrient role and rationale</b>  |
|--|-----------------|---|
| Sardine  | 52              | Marine protein high in EPA and DHA; core omega-3 source. Calcium, Iodine and phosphorus per in-bone sardine meat [ <b>sardinecap</b> ]. |
| Fish Bone Meal (micronized, particle size $\leq 150 \mu\text{m}$ ) | 9.00            | Pet Food Grade; Natural calcium and phosphorus source to balance Ca:P ratio.  |
| Pumpkin Puree  | 4.0             | Fibre; enhances stool quality and regularity  |
| <i>Solids subtotal</i>   | 65.0            | Fixed solids per pouch.   |
| Purified Water   | 43.5            | Purified Water allocation per pouch pre-retort.   |

Table 4.3: ■ CatCore Formulation — Liver (L) SKU

| <b>Ingredient</b>       | <b>Mass (g)</b> | <b>Nutrient role and rationale</b>   |
|-------------------------|-----------------|--|
| Chicken Muscle Cuts     | 28.0            | High-quality amino acid source forming the protein base.                                 |
| Chicken Frame Mince     | 15.0            | Provides bone-derived minerals improving Ca:P ratio; natural chondroitin and glucosamine |
| Chicken Heart           | 10.0            | Taurine and palatability enhancer balancing liver micronutrient load.                    |
| Chicken Liver           | 4.0             | Primary vitamin A and iron contributor; controlled for safety.                           |
| Chicken Egg yolk powder | 4.0             | Choline and lipid source; supports emulsification.                                       |
| Pumpkin puree           | 4.0             | Fibre; enhances stool quality and regularity   |
| <i>Solids subtotal</i>  | 65.0            | Fixed solids per pouch.  |
| Chicken Bone Broth      | 41.5            | Broth allocation per pouch pre-retort.   |

Table 4.4: ■ CatCore Formulations — Gizzard (G) SKU

| <b>Ingredient</b>      | <b>Mass (g)</b> | <b>Nutrient role and rationale</b>  |
|------------------------|-----------------|---|
| Gizzard                | 24.0            | Structural organ supplying connective tissue and natural taurine; defines chew texture. |
| Chicken Muscle Cuts    | 16.0            | High-quality amino acid source forming the protein base.                                |
| Chicken Frame Mince    | 15.0            | Provides bone-derived minerals improving Ca:P ratio;natural chondroitin and glucosamine |
| Chicken Heart          | 10.0            | Taurine and palatability balance; complements high-connective gizzard meat.             |
| <i>Solids subtotal</i> | 65.0            | Fixed solids per pouch.   |
| Chicken Bone Broth     | 41.5            | Broth allocation per pouch pre-retort.  |

Table 4.5: ■ CatCore SKU Formulations — Spleen (M) SKU

| <b>Ingredient</b>             | <b>Mass (g)</b> | <b>Nutrient role and rationale</b>   |
|-------------------------------|-----------------|--|
| Goat Spleen                   | 29.0            | Rich in heme-iron and taurine; moderates phosphorus while enhancing natural palatability.        |
| Goat Frame and Trotters Mince | 20.0            | Adds collagen,natural chondroitin and glucosamine, rich marrow minerals and natural ca:p balance |
| Goat muscle cuts              | 10.0            | High-quality amino acid source forming the skeletal protein base.                                |
| Pumpkin puree                 | 4.0             | Fibre and beta-carotene; enhances stool quality and regularity.                                  |
| Goat Liver                    | 2.0             | Trace vitamin A and B complex inclusion for completeness.  |
| <i>Solids subtotal</i>        | 65.0            | Fixed solids per pouch.  |
| Goat Bone Broth               | 41.5            | Broth allocation per pouch pre-retort.   |

Table 4.6: ■ CatCore SKU Formulations — Kidney (K) SKU

| Ingredient                    | Mass (g) | Nutrient role and rationale   |
|-------------------------------|----------|---|
| Goat Kidney                   | 29.0     | Rich in B vitamins, essential minerals; Pairs with Lamb Spleen for a poultry-free hypoallergenic diet |
| Goat Frame and Trotters Mince | 20.0     | Adds collagen, natural chondroitin and glucosamine, rich marrow and natural Ca:P balance              |
| Goat Heart                    | 14.0     | Adds taurine and flavour, balancing mineral density of kidney.  |
| Goat Liver                    | 2.0      | Minor vitamin A and iron contribution.  |
| <i>Solids subtotal</i>        | 65.0     | Fixed solids per pouch.   |
| Goat Bone Broth               | 41.5     | Broth allocation per pouch pre-retort.  |

Table 4.7: CatCorePro Composition per 10 kg run (or 100 pouches)

| Component                        | Dose per 10 kg    | Per pouch                             |
|----------------------------------|-------------------|---------------------------------------|
| CatCore Fresh Meat Proteins      | 6500g             | 65g                                   |
| Omega-3 Fish Oil PV ≤ 5.0 meq/Kg | 250ml             | 2.50ml                                |
| CatPro Premix                    | 100 g             | 1.0 g                                 |
| Mixed tocopherol liquid premix   | 100 ml            | 1.0 ml                                |
| Palatant Liquid Premix           | 100ml             | 1.0ml                                 |
| Alginate gel - Ca Premix         | 100g              | 1.0g                                  |
| Rendered Bone Broth              | 4150g             | 41.5g                                 |
| Nett Weight per pouch            | 112.5g pre-retort | 101.5g ±0.50; declared weight 100.00g |

- **Catcore Usage:** 6.5 Kg Fresh meat blends per 10 kg production run of CatCore or 65.0 g per 100 g wet food pouch.
- **CatPro Premix:** Complements CatCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together CatCore and CatPro meets AAFCO requirements for complete and balanced nutrition when paired per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P ≥ 1.1:1 within AAFCO recommended limits when paired as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Alginate Gel - Ca Premix:** Alginate gel forms cross-link chain with Calcium under retort heat. Source of 80mg dietary calcium per 100g wet food. Maintains Ca:P ratio.
- **Omega-3 Fish Oil Blend:** Provides functional Omega-3:Omega-6 fatty acids balance.
- **Palatant Premix:** Meat Hydrolysants for palatability.

- **Rendered Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.
- **Low Sodium:** Sodium Alginate Gel provides  $\approx 65$  mg Na per 100g wet food. Palatant Premix provides additional 47.0mg Na to meet electrolyte balance requirements ( $\approx 0.15\%$  Na w/w) as per AAFCO.

# Chapter 5

## DogCore Specifications

### Canonical Specification — Growlrr DogCore v5 (YELLOW Sticker)

#### DogCore SKU7 — Premix Formulation; MOQ 6500g per 10Kg production run

- All DogCore SKUs follow the canonical format per 100 g wet food pouch:
- 65 g dry solid powders
- 5.5 mg premix packets added to broth as per SOP. No Alginate Gel in this SOP.
- 42.0 g  $\pm$ 0.5 g broth fill. Slurry consistency.
- Sealed to achieve 112.5 g nominal pre-retort weight. Pre-Fill QC Check.
- Declared 100 g post-retort with  $\approx$  10% moisture loss. Post-Retort QC Check to 100.5 g.

### Composition for DogCorePro

### Composition for DogCorePro

#### Composition Notes:

- **DogCore Premix:** Provides high quality protein powders and Calcium to be paired 1:1 with CatCorePro meat pouches.
- **DogCore Premix Usage:** 6.5 Kg per 10 kg production run of DogCore or 65.0 g per 100 g wet food pouch.
- **DogPro Premix:** Complements DogCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together DogCore and DogPro meets AAFCO requirements for complete and balanced nutrition when paired with CatCore and CatPro as per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P  $\geq$ 1.4:1 within AAFCO recommended limits when paired with CatCorePro pouches as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Omega-3 Fish Oil Blend:** Provides omega 3:omega 6 balance
- **Palatant Premix:** Meat Hydrolysates for enhanced palatability.
- **Rendered Goat Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.
- **NO Alginate Gel - Ca Premix:** No alginate gel in this SKU. Forms slurry consistency.
- **Low Sodium:** DogCore provides  $\approx$  14.0 mg Na per 100g wet food. Palatant Premix provides additional 47.0mg Na to meet electrolyte balance requirements ( $\approx$  0.061% Na w/w) as per AAFCO when paired with CatCorePro pouches as per diet chart.

Table 5.1:  DogCore SKU Formulations (Three Column Format)

| Ingredient  | Mass (g)           | Nutrient role and r   |
|---|--------------------|---|
| Whey protein concentrate  | 30.0               | Highly digestible co<br>essential amino ac<br>adds solubility.  |
| Egg white powder  | 22.0               | Lean, functional pr<br>structure; natural<br>completeness.      |
| Soy protein isolate   | 4.0                | High-protein, high<br>ancing amino acid<br>ture and consisten   |
| Egg yolk powder   | 4.0                | Natural choline a<br>source; enhances r<br>tion.                |
| Lechitin  | 2.5                | Phospholipid emul<br>persion and oxidati<br>mogeneity in slurry |
| Non-encapsulated Calcium Lactate (20 % Ca)  | 2.0                | Dietary calcium at<br>friendly; Essential l                     |
| Sodium Chloride (Common Salt, NaCl)   | 0.035              | Dietary Sodium, Es<br>ance                                      |
| Mixed tocopherols ( $(\alpha : \beta : \gamma : \delta) = 1.0:0.3:6.0:2.0$ 50% active powder) | 0.300000           | Antioxidant for sh<br>not full dietary E                        |
| Anti-Caking Carrier (q.s)   | 0.165              | q.s and flow aid.   |
| <i>Protein base subtotal</i>  | 65.00              | Fixed solids mass p   |
| MOQ   | 6500.00 $\pm 0.10$ | 6500g DogCore Pr<br>duction run.                                |
| Broth   | 42.5               | Broth phase per po<br>solved premixes pe<br>consistency.        |
| Premixes  | 5.5g               | Added seperately t<br>See table below                           |
| Alginate Gel is omitted from this SKU to ensure tight slurry consistency.                     |                    |   |



Table 5.2: DogCorePro Composition per 10 kg run (or 100 pouches)

| <b>Component</b>               | <b>Dose per 10 kg</b>                                   | <b>Per pouch</b> |
|--------------------------------|---|------------------|
| DogCore Premix                 | 6500g   | 65g              |
| Omega-3 Fish Oil PV≤5.0meq/Kg  | 250ml   | 2.50ml           |
| DogPro Premix                  | 100 g   | 1.0 g            |
| Mixed tocopherol liquid Premix | 100 ml  | 1.0 ml           |
| Palatant Liquid Premix         | 100ml   | 1.0ml            |
| Rendered Bone Broth            | 4200g   | 42.0g            |
| Nett Weight per pouch          | 112.5g pre-retort 101.5g ±0.50; declared weight 100.00g |                  |

## Chapter 6

# Premix Formulations

### CatPro v5 Premix (100 g packet per 10Kg Retort Run) RED Sticker

All weights are expressed in grams (g) per 100 g premix formulation. Carrier (q.s.) to reach 100 g

Table 6.1: Catpro Premix Composition (per 100 g premix)

| Component  | Quantity (g) | Function / Notes   |
|--|--------------|--|
| Choline chloride (60% assay)                         | 32.00000     | Primary methyl donor and carrier base  |
| Taurine  | 15.00000     | Essential amino sulphonate for cats; heat-labile overage included                          |
| Magnesium gluconate (USP grade)                      | 10.00000     | Primary chelator; provides stable Mg source  |
| L-Carnitine (as L-carnitine tartrate )               | 9.000000     | Supports fat metabolism, essential with cooked meat and oil fishes                         |
| Inulin (chicory root powder, FOS)                    | 8.000000     | Prebiotic fibre; improves gut flora stability and stool quality                            |
| Betaine (Trimethylglycine)                           | 6.000000     | Hepatic methyl donor and osmolyte; supports liver fat metabolism and hydration balance     |
| Potassium Citrate (Tripotassium citrate, food grade) | 5.000000     | Secondary chelator; critical for cat urinary health reducing struvite crystal risk         |
| DL-Methionine (USP grade)                            | 3.500000     | Urinary health support; maintains healthy urine pH; Sulfur for protein metabolism          |
| Ascorbic acid (fine powder)                          | 2.000000     | Antioxidant cofactor for metal complex stability   |
| Vitamin K <sub>2</sub> (Menaquinone-7, 1% assay)     | 1.700000     | Provides $\approx 17 \mu\text{g}$ MK-7 per pouch; aids calcium utilization and bone health |
| L-Cysteine (USP grade)                               | 1.500000     | Complements DL-methionine to balance sulfur amino acids and strengthen coat/keratin        |
| Zinc bisglycinate chelate (25% Zn)                   | 1.100000     | Chelated zinc to meet AAFCO limits   |
| Calcium pantothenate (Vitamin B <sub>5</sub> )       | 0.800000     | Coenzyme—A precursor; supports fatty-acid metabolism and adrenal function                  |
| Iron proteinate (20% Fe)                             | 0.750000     | Chelated iron to meet target   |

| Component   | Quantity (g)      | Function / Notes  |
|---|-------------------|---|
| Selenium yeast (0.20% Se)   | 0.550000          | (delivers target $\approx 11 \mu\text{g}$ selenium per 100g wet food pouch)   |
| Niacin ( $\text{B}_3$ )   | 0.250000          | Metabolic cofactor  |
| Copper proteinate (10% Cu)  | 0.300000          | Trace mineral meets requirements  |
| Thiamine ( $\text{B}_1$ )   | 0.190000          | Highly heat-labile B vitamin; ample overage applied   |
| Manganese proteinate (10% Mn)   | 0.150000          | Trace mineral meets requirements  |
| Riboflavin ( $\text{B}_2$ )   | 0.050000          | Energy cofactor   |
| Pyridoxine ( $\text{B}_6$ )   | 0.050000          | Amino-acid metabolism cofactor  |
| Vitamin D <sub>3</sub> (cholecalciferol, 100000 IU g <sup>-1</sup> )                          | 0.035000          | (provides approximately 35 IU per 100 g wet food pouch)   |
| Vitamin A (retinyl palmitate, 320000 IU g <sup>-1</sup> )                                     | 0.015000          | (provides approximately 50 IU per 100 g wet food pouch)   |
| Potassium iodate ( $\text{KIO}_3$ )   | 0.010000          | $\approx 60 \mu\text{g}$ Iodine per 100g wet food pouch. Sardine SKU provides additional $\approx 20 \mu\text{g}$ <b>[sardinecap]</b> |
| Biotin (Vitamin B7), Pharma Grade D-Biotin  | 0.008000          | Skin/coat support; very low inclusion, provides 80 $\mu\text{g}$ biotin per 100g wet food pouch                                       |
| Mixed tocopherols ( $(\alpha : \beta : \gamma : \delta) = 1.0:0.3:6.0:2.0$ 50% active powder) | 1.000000          | Antioxidant for premix shelf-life stability (not primary source of dietary vitamin E)   |
| Anti-caking carrier (q.s)   | 1.042000          | q.s to 100.000000 g per premix packet   |
| <b>Total</b>  | <b>100.000000</b> | Use one 100 packet per 10 kg run. MOQ 10 Packets.   |

## Composition for CatCorePro

### Composition Notes:

- **CatCore:** Provides high quality muscle, organ, skeletal and fish meat proteins. Primary source of proteins, fats, vitamins, minerals.
- **Catcore Usage:** 6.5 Kg Fresh meat blends per 10 kg production run of CatCore or 65.0 g per 100 g wet food pouch.
- **CatPro Premix:** Complements CatCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together CatCore and CatPro meets AAFCO requirements for complete and balanced nutrition when paired per diet chart.

Table 6.2: CatCorePro Composition per 10 kg run (or 100 pouches)

| Component                      | Dose per 10 kg   | Per pouch |
|--------------------------------|--|-----------|
| CatCore Fresh Meat Protiens    | 6500g  | 65.0g     |
| Omega-3 Fish Oil PV<=5.0meq/Kg | 250ml  | 2.50ml    |
| CatPro Premix                  | 100 g  | 1.0 g     |
| Mixed tocopherol liquid premix | 100 ml   | 1.0 ml    |
| Palatant Liquid Premix         | 100ml  | 1.0ml     |
| Alginate gel - Ca Premix       | 100g   | 1.0g      |
| Rendered Bone Broth            | 4150g  | 41.5g     |
| Nett Weight per pouch          | 112.5g pre-retort 101.5g $\pm$ 0.50; declared weight 100.00g |           |

- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P  $\geq$ 1.1:1 within AAFCO recommended limits when paired as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Alginate Gel - Ca Premix:** Alginate gel forms cross-link chain with Calcium under retort heat. Source of 80mg dietary calcium per 100g wet food. Maintains Ca:P ratio.
- **Omega-3 Fish Oil Blend:** Provides functional Omega-3:Omega-6 fatty acids balance.
- **Palatant Premix:** Meat Hydrolysants for palatability.
- 
- **Rendered Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.

**DogPro v5 Premix (100 g packet per 10 kg retort run)**

All weights are expressed in grams (g) per 100 g premix formulation. Carrier (q.s.) to reach 100 g.

Table 6.3: DogPro v5 Premix Composition (per 100 g premix)

| Component   | Quantity (g) | Function / Notes   |
|---|--------------|--|
| Choline chloride (60% assay)  | 20.000000    | Primary methyl donor and carrier base                              |
| Taurine ( $\geq 99\%$ )   | 10.000000    | Essential sulphonic amino acid; margin for breed/diet variability  |
| Inulin (chicory root powder, FOS)                                     | 12.000000    | Prebiotic fibre; gut flora stability and stool quality             |
| Magnesium gluconate (USP grade)                                       | 10.000000    | Secondary chelator; provides Mg and buffering capacity             |
| L-Carnitine (as L-carnitine tartrate)                                 | 7.500000     | Supports fat metabolism; useful with added fish oil                |
| Glucosamine HCl   | 6.000000     | Joint-support amino-sugar; heat-stable through retort              |
| Betaine (Trimethylglycine)  | 6.000000     | Hepatic methyl donor and osmolyte; supports liver function         |
| Potassium citrate (tripotassium citrate)                              | 5.000000     | Urinary pH control and citrate chelation                           |
| Collagen peptides (hydrolysed bovine)                                 | 5.000000     | Provides glycine/proline for connective tissue; improves mouthfeel |
| Methylsulfonylmethane (MSM)   | 4.000000     | Sulfur donor; complements glucosamine for joint health             |
| Zinc bisglycinate chelate (25% Zn)                                    | 3.000000     | Chelated zinc to meet AAFCO requirements                           |
| Iron proteinate (20% Fe)  | 2.000000     | Chelated iron to meet AAFCO Fe targets                             |
| DL-Methionine (USP grade)   | 3.500000     | Sulfur amino acid and urinary acidifier support                    |
| Vitamin K <sub>2</sub> (Menaquinone-7, 1% assay)                      | 1.700000     | $\approx 17 \mu\text{g}$ MK-7 per pouch; aids Ca utilisation       |
| L-Cysteine (USP grade)  | 0.500000     | Complements methionine for sulfur balance                          |
| Selenium yeast (0.20% Se)   | 0.550000     | Delivers $\approx 11 \mu\text{g}$ Se per pouch                     |
| Copper proteinate (10% Cu)  | 0.300000     | Trace mineral meets AAFCO limits                                   |
| Niacin (B <sub>3</sub> )  | 0.250000     | Metabolic cofactor   |
| Thiamine (B <sub>1</sub> )  | 0.190000     | Heat-labile B vitamin; overage included                            |
| Manganese proteinate (10% Mn)   | 0.150000     | Trace mineral floor  |
| Vitamin D <sub>3</sub> (cholecalciferol, 100,000 IU g <sup>-1</sup> ) | 0.115000     | Provides $\approx 115$ IU per pouch                                |

| Component  | Quantity (g)                           | Function / Notes   |
|--|--|--|
| Vitamin E (DL- $\alpha$ -tocopheryl acetate, 400 IU g <sup>-1</sup> )                                | 0.065000                               | Antioxidant; retort overage included                             |
| Riboflavin (B <sub>2</sub> )   | 0.050000                               | Energy cofactor  |
| Pyridoxine (B <sub>6</sub> )   | 0.050000                               | Amino-acid metabolism cofactor                                   |
| Vitamin A (retinyl palmitate, 320,000 IU g <sup>-1</sup> )   | 0.040000                               | Provides $\approx$ 100 IU per pouch; overage for retort loss     |
| Potassium iodate (KIO <sub>3</sub> )   | 0.015000                               | $\approx$ 90 $\mu$ g I per pouch                                 |
| Biotin (Vitamin B7), Pharma-grade D-Biotin   | 0.008000                               | Skin/coat support ( $\approx$ 80 $\mu$ g per pouch)              |
| Mixed tocopherols (( $\alpha$ : $\beta$ : $\gamma$ : $\delta$ ) = 1.0:0.3:6.0:2.0 50% active powder) | 1.000000                               | Antioxidant for shelf-life stability support, not full dietary E |
| Anti-caking carrier (q.s.)   | 1.000000                               | Flow aid; adjusted to bring total premix to 100.000000 g         |
| <b>Total</b>   | <b>100.000000 <math>\pm</math> 0.1</b> | One 100 g DogPro premix packet per 10 kg run. MOQ 10 Packets.    |

## Composition for DogCorePro

Table 6.4: DogCorePro Composition per 10 kg run (or 100 pouches)

| Component                            | Dose per 10 kg    | Per pouch                                  |
|--------------------------------------|-------------------|--|
| DogCore Premix                       | 6500g             | 65g  |
| Omega-3 Fish Oil PV $\leq$ 5.0meq/Kg | 250ml             | 2.50ml                                     |
| DogPro Premix                        | 100 g             | 1.0 g                                      |
| Mixed tocopherol liquid Premix       | 100 ml            | 1.0 ml                                     |
| Palatant Liquid Premix               | 100ml             | 1.0ml                                      |
| Rendered Bone Broth                  | 4200g             | 42.0g                                      |
| Nett Weight per pouch                | 112.5g pre-retort | 101.5g $\pm$ 0.50; declared weight 100.00g |

## Composition for DogCorePro

### Composition Notes:

- **DogCore Premix:** Provides high quality protien powders and Calcium to be paired 1:1 with CatCorePro meat pouches.
- **DogCore Premix Useage:** 6.5 Kg per 10 kg production run of DogCore or 65.0 g per 100 g wet food pouch.

- **DogPro Premix:** Complements DogCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together DogCore and DogPro meets AAFCO requirements for complete and balanced nutrition when paired with CatCore and CatPro as per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P  $\geq$  1.4:1 within AAFCO recommended limits when paired with CatCorePro pouches as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Omega-3 Fish Oil Blend:** Provides omega 3:omega 6 balance
- **Palatant Premix:** Meat Hydrolysates for enhanced palatability.
- 
- **Rendered Goat Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.
- **NO Alginate Gel - Ca Premix:** No alginate gel in this SKU. Forms slurry consistency.
- **Low Sodium:** DogCore provides  $\approx$  14.0 mg Na per 100g wet food. Palatant Premix provides additional 47.0mg Na to meet electrolyte balance requirements ( $\approx$  0.061% Na w/w) as per AAFCO when paired with CatCorePro pouches as per diet chart.

**Gel / Alginate-Encapsulated Calcium Premix (100 g packet)**

Table 6.5: Gel / Alginate-Calcium Premix Composition (per 100 g premix)

| Component                         | Quantity (g)        | Remarks   |
|-----------------------------------|---------------------|---|
| Sodium alginate                   | 60.000000           | High-viscosity grade (200–300 cP @ 1%)                        |
| Encapsulated Ca-lactate catalyst  | 39.5000000          | High melting heat triggered polymeric microgranular end       |
| Anti-caking carrier (carrier q.s) | 0.5000000           | q.s carrier   |
| <b>Total</b>                      | <b>100.000000 g</b> | <b>Use 1 packet per 10 kg run (1 g / pouch); MOQ Premix 1</b> |

*Encapsulated Calcium Lactate — Vendor Specification*

- **Active:** Calcium lactate (encapsulated) — *elemental Ca 20 % w/w nominal*.
- **Physical form:** free-flowing microgranules; target particle-size  $D_{50} \leq 300 \mu\text{m}$ ; no fragments  $>1 \text{ mm}$ .
- **Coating:** food-grade high-melting lipid or heat-triggered polymeric coat; no low-melt coatings that release at  $\leq 45^\circ\text{C}$ .
- **Release profile (validated):**
  - $\leq 10\%$  release (w/w active) after 30 min at  $45^\circ\text{C}$  in aqueous broth under standard agitation.
  - $\geq 80\%$  release (w/w active) after full retort cycle (e.g.  $121^\circ\text{C}$ , process-specific hold time) — vendor to provide thermal-release validation that matches our retort cycle.
- **Solubility / behavior:** core salt (calcium lactate) is water-soluble when unencapsulated; encapsulate must remain intact in mix/fill conditions and release under retort thermal/pressure profile.
- **Taste / organoleptic:** coated granules produce *no detectable* metallic/alkaline off-flavour at the intended inclusion (acceptance by sensory panel required).
- **Stability:** shelf-stable at ambient ( $\leq 30^\circ\text{C}$ ) for  $\geq 12$  months; no migration or leaching of core under storage (vendor stability data required).
- **Heat/Retort compatibility:** coating must not soften and bleed during pre-retort hold or during processing prior to fill; vendor to certify retort survivability and release curve.
- **Microbiological:** total plate count and yeast/mould within vendor spec; free of pathogens; supply certificate of analysis (CoA) with each lot.
- **Labeling:** declare as “Calcium (as encapsulated calcium lactate premix)”; provide elemental Ca per g premix on CoA.
- **QC tests (supplier deliverables):**
  1. Particle-size distribution (laser/ $D_{50}$ ) report.
  2. Thermal-release study ( $45^\circ\text{C}$  hold and retort equivalent) with
  3. Elemental Ca assay (ICP) confirming  $20\% \pm 2\%$ .
  4. Sensory release check post-retort (3 replicate pouches).

**Antioxidant Liquid Premix for ALL SKUs- 100ml per 10kg Production Run**

*Note: This Anti-oxidant blend premix supplies 100ml organic extracts, mixed tocopherols and lecithin per 10Kg of wet food production.*

**Palatant Premix for All SKUs- 100ml per 10kg Production Run**

*Note: This Palatant Premix supplies shelf stable palatant meat hydrolysate and sodium for electrolyte balance for all SKUs at 100ml per 10Kg production or 1ml per 100g wet food pouch.*



Table 6.6: Palatant Premix Composition (per 100 ml premix)

| Component  | Quantity (ml)       | Remarks                                   |
|--|---------------------|---|
| Rosemary Extract   | 28.000000           | Primary antioxidant                       |
| Sunflower lecithin (food-grade)  | 27.000000           | Phospholipid emulsifier supporting        |
| Grape Seed Extract Concentrates  | 24.000000           | proanthocyanidins with antioxidant        |
| Citric acid aq.soultion  | 10.000000 (25% w/v) | Supports anti-oxidation; pH buffer        |
| Mixed tocopherols ( $(\alpha : \beta : \gamma : \delta) = 1.0:0.3:6.0:2.0$ ) | 10.000000           | Secondary antioxidant;Provides pri        |
| Glycerol monostearate GMS (q.s)  | 1.00000             | Carrier (q.s) providing robust emuls      |
| <b>Total</b>   | <b>100.000000 g</b> | <b>Use 1 packet per 10 kg run (1 g/po</b> |

Table 6.7: Palatant Premix Composition (per 100 ml premix)

| Component                             | Quantity (ml)       | Remarks   |
|---------------------------------------|---------------------|---|
| Hydrolyzed meat protein (non-poultry) | 87.5000             | Enzymatic hydrolysate palatant, $\geq 45\%$ (dry basis) |
| Sodium Chloride (NaCl; Common Salt)   | 12.00               | Electrolyte Balance As per AAFCO requirements           |
| Rosemary Extract                      | 0.1000000           | Shelf stable antioxidant                                |
| Potassium Sorbate                     | 0.1000000           | Shelf stable preservative                               |
| Glycerol monostearate                 | 0.100000            | Emulsifier  |
| Carrier (q.s)                         | 0.20                | Total: 100.00ml sealed amber bottle                     |
| <b>Total</b>                          | <b>100.000000 g</b> | <b>Use 100ml per 10 kg run (1 g/pouch); MOQ Premi</b>   |

## **Chapter 7**

# **Quality Control — Incoming Raw Materials Handling and COA**

## Incoming Raw Material QC & Storage SOP

### 1. Scope

Applies to all animal-derived and perishable inputs for Growlrr CatCore and DogCore lines: hearts, gizzards, livers, kidneys, spleens, frame mince, muscle meats, sardine, fish bone meal, egg yolk powder, chicken and goat frames, trotters, neck, back frame and bones for broth, red pumpkin and ancillary dry materials.

### 2. Receiving Procedure

- Check **delivery temperature** on arrival. Frozen:  $\leq -18^{\circ}\text{C}$ ; Chilled:  $0-4^{\circ}\text{C}$ ; Dried powders: ambient  $\leq 25^{\circ}\text{C}$ , RH  $\leq 65\%$ .
- Inspect **packaging**: intact, labelled with supplier, lot #, weight, COA reference.
- Record receipt: time, supplier, lot #, temperature, and QC initials.

### 3. Organ & Meat Blocks (heart, gizzard, liver, lamb, kidney, spleen, lean muscle cuts)

| Parameter       | Accept  | Reject / Action                        |
|-----------------|---|--|
| Temp on arrival | $\leq 4^{\circ}\text{C}$ (chilled) or $\leq -18^{\circ}\text{C}$ (frozen)         | $> 5^{\circ}\text{C}$ or thawed edges  |
| Appearance      | Bright natural colour   | Grey/green discolouration, sticky film |
| Odour           | Clean, fresh  | Sour, rancid, putrid                   |
| Texture         | Firm, resilient   | Mushy, slimy                           |
| Foreign matter  | None  | Visible contamination                  |
| COA (micro)     | TVC $\leq 10^5$ CFU/g; <i>E. coli</i> $< 10$ CFU/g; <i>Salmonella</i> Absent/25 g | Fail = Reject                          |

**Storage:** Chilled lots  $0-2^{\circ}\text{C}$  (use within 48 h). Frozen lots  $-18^{\circ}\text{C}$  (use within 3 months). Thaw under refrigeration only.

### 4. Fish (sardine)

| Parameter         | Accept                                 | Reject / Action   |
|-------------------|--|---|
| Temp              | $\leq -18^{\circ}\text{C}$ (frozen)    | $> -12^{\circ}\text{C}$   |
| Appearance        | Bright eyes, metallic skin, firm flesh | Dull eyes, brown gills, soft texture  |
| Odour             | Clean sea smell                        | Ammoniac, rancid  |
| Hg (COA)          | $\leq 0.05$ ppm                        | $> 0.05$ ppm Hg $\Rightarrow$ Reject lot  |
| Peroxide PV (COA) | $\leq 5.0$ meq/kg                      | $> 5.0$ meq/kg or missing COA and cold-chain logs $\Rightarrow$ Reject lot if older than 1 week |

**Storage:**  $-18^{\circ}\text{C}$ ; thaw at  $\leq 4^{\circ}\text{C}$  and drain before use.

### 5. Egg Yolk Powder

| Parameter | Accept  | Reject         |
|-----------|---|----------------|
| Moisture  | $\leq 4\%$                                      | $> 5\%$        |
| Colour    | Deep yellow to orange                           | Pale / brown   |
| Odour     | Clean, eggy                                     | Rancid / musty |
| Micro     | TPC $\leq 10^3$ CFU/g; <i>Salmonella</i> Absent | Fail = Reject  |

**Storage:** airtight sealed vacuum packs,  $\leq 15^{\circ}\text{C}$ ,  $\text{RH} \leq 60\%$ , away from light. Shelf life 12 months unopened.

## 6. Trotter; neck, frame and bones (for mince and broth)

| Parameter   | Accept   | Reject                           |
|-------------|--|----------------------------------|
| Temp        | $\leq -18^{\circ}\text{C}$                             | Thawed / $> -12^{\circ}\text{C}$ |
| Cleanliness | No feathers, hide, claws, hooves, dirt, tissue residue | Visible contamination            |
| Odour       | Neutral  | Rancid / decomposing             |
| Source      | Food-grade, antibiotic-free poultry                    | Unverified source                |

**Storage:** frozen  $-18^{\circ}\text{C}$ ; feed directly into broth kettle.

## 7. Dried Additives & Powders

Inspect packaging and COA (valid  $\leq 6$  months). Moisture  $\leq 6\%$ ; caking = Reject. Store at  $20-25^{\circ}\text{C}$ ,  $\text{RH} \leq 60\%$ , sealed.

## 8. Temperature & Storage Map

| Material                    | Storage      | Range                                       | Max Hold Time |
|-----------------------------|--------------|---|---------------|
| Frozen meats / fish / bones | Freezer      | $-18^{\circ}\text{C} \pm 2^{\circ}\text{C}$ | 3 mo          |
| Chilled organs              | Chiller      | $0-2^{\circ}\text{C}$                       | 48 h          |
| Egg yolk powder             | Dry store    | $\leq 15^{\circ}\text{C}$                   | 12 mo         |
| Dry premixes / hydrolysates | Dry store    | $15^{\circ}\text{C}$                        | 12 mo         |
| Tocopherol-lecithin liquid  | Refrigerated | $4-8^{\circ}\text{C}$                       | 6 mo          |
| Packaging materials         | Clean room   | $\leq 25^{\circ}\text{C}$                   | 12 mo         |

## 9. Actions

- **Accept:** meets all criteria  $\Rightarrow$  Label “QC Approved”.
- **Hold:** minor deviation; quarantine pending investigation.
- **Reject:** fails safety/COA  $\Rightarrow$  return or destroy per SOP.
- Record all decisions in **Incoming Material Log (Form QC-Fresh-01)**.

## Incoming Premix QC & Dispensing SOP

**Scope:** Covers all Growlrr premixes

### 1. Receipt & Identification

1. Verify seals and labels on arrival.
2. Cross-check supplier COA with Growlrr specification & file it in Build Binder.
3. Assign internal Lot ID: PREMIX-TYPE/YYYYMMDD/SEQ.
4. Create Forms QC-Premix-01, QC-Premix-02, QC-Premix-03 for Incoming Materials log, Test method and Acceptance log, Non-compliance/Damage or Reject log.
5. Record incoming premix packs in Form QC-Premix-01; store verified packets  $\leq 25^{\circ}\text{C}$ ,  $\text{RH} < 60\%$ .
6. Rejected lots should be recorded in Form QC-Premix-03 with supervisor sign-off and samples preserved for inspection.

| Premix Type                               | Packaging                  | MOQ   |
|---|----------------------------|-------|
| <b>Solid Premix:</b>                      |                            |       |
| CatPro V5 Premix                          | 100g sealed pouches        | 1.5Kg |
| DogCore V5 Premix                         | 100g sealed pouches        | 1.5Kg |
| DogPro V5 Premix                          | 100g sealed pouches        | 1.5Kg |
| Alginate Gel - Encapsulated Calcium Premi | 100g sealed pouches        | 1.5Kg |
| <b>Liquid Premix:</b>                     |                            |       |
| Palatant V5 Premix                        | 100ml sealed amber bottles | 1.5L  |
| Blended Antioxidant V5 Premix             | 100ml sealed amber bottles | 1.5L  |
| Shelf Stable Blended Omega-3 Fish Oil     | 250ml sealed amber bottles | 1.5L  |

## 2. Subdivision & Labeling

1. Portion solids into 100 g and liquids into 100 mL packs.
2. Label each pack with name, Lot ID, date, net quantity, operator initials.
3. Mark —"For Internal Use Only — add entire pack per 10 kg run.—"
4. Retain one sealed control pack per lot for 24 months.

## 3. Verification Tests

| Test             | Method                                 | Acceptance          |
|------------------|--|---------------------|
| Weight           | Electronic balance                     | ± 0.5 g from target |
| Moisture (solid) | Moisture meter                         | Within spec         |
| Visual           | Free-flowing, no lumps                 | Pass                |
| Label            | Correct name, lot, date                | Pass                |
| Incoming COA     | Supplier COA with traceability on file | Pass                |

Record log in Form QC-Premix-02 and save copy for Floor use sign-off during production

## 4. Storage

Solids: ≤ 25°C, dry; Liquids: amber HDPE, avoid sunlight. FIFO by Lot ID. Maintain all entry/ exit logs.

## 6. Documentation

Maintain:

- Binder with all Supplier documents, COA, receipts, Forms QC-Premix-01, QC-Premix-02 and QC-Premix-03
- Scan and digitize the binder at the time of completion of production and upload to cloud server.

## Chapter 8

# Quality Control — Incoming Premix Handling and COA

### COA and Incoming QC - CatPro v5 (100 g packet) with RED Sticker

All weights are expressed in grams (g) per 100 g premix formulation. Carrier (q.s.) to reach 100 g

Table 8.1: Catpro Premix Composition COA and Incoming QC (per 100 g premix)

| Parameter                       | Unit               | Spec                                       | CAS No. | Method / Instru-<br>ment   | Result /<br>Comments |
|---------------------------------|--------------------|--|---------|----------------------------|----------------------|
| <b>Identification and Batch</b> |                    |  |         |                            |                      |
| Product name or code            | —                  | CatPro v5 (100 g packet)                   | —       | Visual label check         |                      |
| Color Coded RED Sticker         | —                  | Red  | —       | Visual                     |                      |
| Lot or Batch number             | —                  | Supplier lot number present                | —       | Visual                     |                      |
| Manufacture date                | —                  | Present                                    | —       | Visual                     |                      |
| Expiry or Best before           | —                  | Present                                    | —       | Visual                     |                      |
| <b>Physical and Packaging</b>   |                    |  |         |                            |                      |
| Net packet mass                 | g                  | 100.00 +/- 0.20                            | —       | Analytical balance (tare)  |                      |
| Appearance                      | —                  | Free flowing, no caking, no oil separation | —       | Visual inspection          |                      |
| Odour                           | —                  | Characteristic, not rancid or off odour    | —       | Sensory                    |                      |
| Color                           | —                  | Off white to pale beige                    | —       | Visual                     |                      |
| Particle size (D90)             | um                 | <= 250                                     | —       | Sieve or laser diffraction |                      |
| Bulk density                    | g mL <sup>-1</sup> | 0.40 to 0.65                               | —       | Volumetric fill test       |                      |
| Moisture (loss on drying)       | % w/w              | <= 4.0                                     | —       | AOAC 925.10 (LOD)          |                      |

#### Composition (assay) - key actives per 100 g packet

| Parameter                      | Unit            | Spec                                     | CAS No.            | Method / Instru-<br>ment | Result / Com-<br>ments                     |
|--------------------------------|-----------------|--|--------------------|--------------------------|--|
| Component                      | Quantity<br>(g) | Assay/Grade<br>± (g)                     | Tolerance<br>± (g) | CAS Number               | Supplier Specifi-<br>cation                |
| Choline chloride               | 32.000          | 60% assay                                | 0.500              | 67-48-1                  | USP/FCC grade;<br>free-flowing pow-<br>der |
| Taurine                        | 15.000          | ≥98.5%<br>purity                         | 0.200              | 107-35-7                 | USP grade; phar-<br>maceutical quality     |
| Magnesium gluconate            | 10.000          | USP grade                                | 0.100              | 3632-91-5                | Dihydrate form;<br>food grade              |
| L-Carnitine tartrate           | 9.000           | ≥98%<br>L-carnitine                      | 0.100              | 36687-82-8               | 2:1 L-<br>carnitine:tartrate<br>ratio      |
| Inulin (chicory root)          | 8.000           | FOS ≥90%                                 | 0.100              | 9005-80-5                | Prebiotic fiber;<br>food grade             |
| Betaine (TMG)                  | 6.000           | ≥98% pu-<br>rity                         | 0.100              | 107-43-7                 | Anhydrous; food<br>grade                   |
| Potassium citrate              | 5.000           | Tripotassium<br>citrate<br>food<br>grade | 0.050              | 866-84-2                 | Monohydrate;<br>USP/FCC                    |
| DL-Methionine                  | 3.500           | USP grade<br>≥98.5%                      | 0.050              | 59-51-8                  | Free amino acid<br>form                    |
| Ascorbic acid                  | 2.000           | ≥99% pu-<br>rity                         | 0.050              | 50-81-7                  | Fine powder; USP<br>grade                  |
| Vitamin K <sub>2</sub> (MK-7)  | 1.700           | 1.0%<br>menaquinone-<br>7 assay          | 0.050              | 2124-57-4                | Spray-dried on<br>carrier; ≥1.0%<br>MK-7   |
| L-Cysteine                     | 1.500           | USP grade<br>≥98%                        | 0.050              | 52-90-4                  | Free base or HCl<br>form                   |
| Zinc bisglycinate chelate      | 1.100           | 25% ele-<br>mental<br>Zn                 | 0.050              | 14281-83-5               | Chelated form;<br>GRAS                     |
| Calcium pantothenate           | 0.800           | ≥98% B <sub>5</sub>                      | 0.050              | 137-08-6                 | D-form; USP<br>grade                       |
| Iron proteinate                | 0.750           | 20% ele-<br>mental<br>Fe                 | 0.050              | 9007-73-2                | Chelated organic<br>form                   |
| Selenium yeast                 | 0.550           | 0.20% ele-<br>mental Se                  | 0.050              | Various                  | Organic selenium;<br>food grade            |
| Copper proteinate              | 0.300           | 10% ele-<br>mental<br>Cu                 | 0.030              | 9007-73-2                | Chelated organic<br>form                   |
| Niacin (B <sub>3</sub> )       | 0.250           | ≥99% pu-<br>rity                         | 0.020              | 59-67-6                  | Nicotinic acid or<br>niacinamide           |
| Thiamine HCl (B <sub>1</sub> ) | 0.190           | ≥99% pu-<br>rity                         | 0.020              | 67-03-8                  | Hydrochloride<br>form; USP                 |

| Parameter                        | Unit  | Spec                          | CAS No. | Method / Instrument                 | Result / Comments                      |
|----------------------------------|-------|-------------------------------|---------|-------------------------------------|--|
| Manganese proteinate             | 0.150 | 10% elemental Mn              | 0.020   | 9007-73-2                           | Chelated organic form                  |
| Riboflavin (B <sub>2</sub> )     | 0.050 | ≥98% purity                   | 0.010   | 83-88-5                             | USP grade; fine powder                 |
| Pyridoxine HCl (B <sub>6</sub> ) | 0.050 | ≥98% purity                   | 0.010   | 58-56-0                             | Hydrochloride form; USP                |
| Vitamin D <sub>3</sub>           | 0.035 | 100000 IU/g cholecalciferol   | 0.005   | 67-97-0                             | Spray-dried; stabilized                |
| Vitamin A palmitate              | 0.015 | 320000 IU/g retinyl palmitate | 0.005   | 79-81-2                             | Spray-dried; stabilized                |
| Potassium iodate                 | 0.010 | ≥99.5% KIO <sub>3</sub>       | 0.002   | 7758-05-6                           | Food grade; iodine source              |
| D-Biotin (B <sub>7</sub> )       | 0.008 | ≥98% purity                   | 0.002   | 58-85-5                             | Pharmaceutical grade; pure crystalline |
| Mixed tocopherols ( 50% active)  | 1.000 |                               | 0.050   | ((α : β : γ : δ) = 1.0:0.3:6.0:2.0) | GRAS stabilizer                        |

**Microbiology**

|                                 |                     |              |       |           |             |
|---------------------------------|---------------------|--------------|-------|-----------|-------------|
| Total aerobic plate count (TPC) | cfu g <sup>-1</sup> | <= 1e4       | —     | ISO 4833  | Plate count |
| Yeast and mould                 | cfu g <sup>-1</sup> | <= 1e3       | —     | ISO 21527 | Plate count |
| Salmonella spp.                 | per 25 g            | Not detected | de- — | ISO 6579  | Enrichment  |
| Enterobacteriaceae              | cfu g <sup>-1</sup> | <= 1e3       | —     | ISO 21528 |             |

**Contaminants and Safety**

|                   |                     |                           |           |          |  |
|-------------------|---------------------|---------------------------|-----------|----------|--|
| Heavy metals (Pb) | mg kg <sup>-1</sup> | <= 0.5                    | 7439-92-1 | ICP MS   |  |
| Heavy metals (Cd) | mg kg <sup>-1</sup> | <= 0.2                    | 7440-43-9 | ICP MS   |  |
| Aflatoxin (total) | ug kg <sup>-1</sup> | <= 10                     | Various   | LC MS MS |  |
| Melamine          | mg kg <sup>-1</sup> | Not detected or Below LOQ | 108-78-1  | LC MS MS |  |

**Physical and Stability**

|                                       |                                     |         |   |                     |                   |
|---------------------------------------|-------------------------------------|---------|---|---------------------|-------------------|
| Bulk water activity (a <sub>w</sub> ) | —                                   | <= 0.60 | — | Aqualab or Rotronic |                   |
| Peroxide value (if oil included)      | meq O <sub>2</sub> kg <sup>-1</sup> | <= 5.0  | — | AOCS Cd 8b 90       | NA for dry premix |

**Packaging and Storage**



| Parameter                   | Unit         | Spec                                       | CAS No. | Method / Instru-<br>ment | Result /<br>Comments | Com- |
|-----------------------------|--------------|--|---------|--------------------------|----------------------|------|
| Packet seal integrity       | —            | No leaks, hermetic seal                    | —       | Vacuum or visual         |                      |      |
| Pouch labelling             | —            | Lot, Mfg date, Expiry, COA                 | —       | Visual                   |                      |      |
| Storage conditions          | —            | Store dry, 10 to 20 C, RH < 60%            | —       | Visual or log            |                      |      |
| <b>Acceptance</b>           |              |  |         |                          |                      |      |
| Sample size for incoming QC | —            | 1 packet per 10 boxes or ISO sampling plan | —       | QA plan                  |                      |      |
| Release decision            | —            | Accept or Reject or Hold                   | —       | QA manager signature     |                      |      |
| <b>Sign off</b>             |              |  |         |                          |                      |      |
| Checked by (incoming QC)    | Name or Sign | Date                                       | —       | Comments                 |                      |      |
| Approved by (QA Manager)    | Name or Sign | Date                                       | —       | Comments                 |                      |      |

## Composition for CatCorePro

Table 8.2: CatCorePro Composition per 10 kg run (or 100 pouches)

| Component                      | Dose per 10 kg    | Per pouch                                  |
|--------------------------------|-------------------|--|
| CatCore Fresh Meat Protiens    | 6500g             | 65g  |
| Omega-3 Fish Oil PV<=5.0meq/Kg | 250ml             | 2.50ml                                     |
| CatPro Premix                  | 100 g             | 1.0 g                                      |
| Mixed tocopherol liquid premix | 100 ml            | 1.0 ml                                     |
| Palatant Liquid Premix         | 100ml             | 1.0ml                                      |
| Alginate gel - Ca Premix       | 100g              | 1.0g                                       |
| Rendered Bone Broth            | 4150g             | 41.5g                                      |
| Nett Weight per pouch          | 112.5g pre-retort | 101.5g $\pm$ 0.50; declared weight 100.00g |

### Composition Notes:

- **CatCore:** Provides high quality muscle, organ, skeletal and fish meat proteins. Primary source of proteins, fats, vitamins, minerals.
- **Catcore Usage:** 6.5 Kg Fresh meat blends per 10 kg production run of CatCore or 65.0 g per 100 g wet food pouch.
- **CatPro Premix:** Complements CatCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together CatCore and CatPro meets AAFCO requirements for complete and balanced nutrition when paired per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P  $\geq$  1.1:1 within AAFCO recommended limits when paired as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Alginate Gel - Ca Premix:** Alginate gel forms cross-link chain with Calcium under retort heat. Source of 80mg dietary calcium per 100g wet food. Maintains Ca:P ratio.
- **Omega-3 Fish Oil Blend:** Provides functional Omega-3:Omega-6 fatty acids balance.
- **Palatant Premix:** Meat Hydrolysates for palatability.
- **Rendered Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.
- **Low Sodium:** Sodium Alginate Gel provides  $\approx$  65 mg Na per 100g wet food. Palatant Premix provides additional 47.0mg Na to meet electrolyte balance requirements ( $\approx$  0.15% Na w/w) as per AAFCO.

## COA and Incoming QC - DogCore Protein Base (6500 g solids per Sealed Packet) with YELLOW Sticker

All weights are expressed in grams (g)

Table 8.3: DogCore Protein Base COA and Incoming QC (per 100 g wet food pouch)

| Parameter                            | Unit               | Spec                                 | CAS No.         | Method / Instru-<br>ment   | Result /<br>Comments                 | Com- |
|--------------------------------------|--------------------|--------------------------------------|-----------------|----------------------------|--------------------------------------|------|
| <b>Identification and Batch</b>      |                    |                                      |                 |                            |                                      |      |
| Product name or code                 | —                  | DogCore Protein Base (6500 g)        | —               | Visual label check         |                                      |      |
| Color Coded YELLOW Sticker           | —                  | Yellow                               | —               | Visual                     |                                      |      |
| Lot or Batch number                  | —                  | Supplier lot present                 | —               | Visual                     |                                      |      |
| Manufacture date                     | —                  | Present                              | —               | Visual                     |                                      |      |
| Expiry or Best before                | —                  | Present                              | —               | Visual                     |                                      |      |
| <b>Physical and Packaging</b>        |                    |                                      |                 |                            |                                      |      |
| Net solids mass per pouch            | g                  | 6500.00 ± 0.50                       | —               | Analytical balance         |                                      |      |
| Appearance                           | —                  | Fine powder blend, free-flowing      | —               | Visual inspection          |                                      |      |
| Odour                                | —                  | Characteristic protein, no rancidity | —               | Sensory                    |                                      |      |
| Color                                | —                  | Off-white to cream                   | —               | Visual                     |                                      |      |
| Particle size (D90)                  | μm                 | ≤ 300                                | —               | Sieve or laser diffraction |                                      |      |
| Bulk density                         | g mL <sup>-1</sup> | 0.35 to 0.60                         | —               | Volumetric fill test       |                                      |      |
| Moisture (LOD)                       | % w/w              | ≤ 5.0                                | —               | AOAC 925.10 (LOD)          |                                      |      |
| <b>Composition per 6500g (assay)</b> |                    |                                      |                 |                            |                                      |      |
| Component                            | Quantity (g)       | Assay/Grade                          | Tolerance ± (g) | CAS Number                 | Supplier Specification               |      |
| Whey protein concentrate             | 3000.000           | ≥80% protein (WPC80)                 | 0.500           | 92129-90-3                 | Food grade; instantized; low lactose |      |
| Egg white powder                     | 2200.000           | ≥80% protein                         | 0.500           | 8001-57-6                  | Spray-dried; food grade; pasteurized |      |
| Soy protein isolate                  | 400.000            | ≥90% protein                         | 0.200           | 9010-10-0                  | Non-GMO preferred; food grade        |      |

| Parameter                          | Unit                | Spec                  | CAS No. | Method / Instru-<br>ment  | Result / Com-<br>ments  |
|------------------------------------|---------------------|-----------------------|---------|---|---|
| Egg yolk powder                    | 400.000             | Food grade            | 0.200   | 8001-57-6   | Spray-dried; high choline content                               |
| Lecithin                           | 250.000             | ≥95% phospho-lipids   | 0.200   | 8002-43-5   | Soy or sunflower; food grade emulsifier                         |
| Calcium lactate (non-encapsulated) | 200.000             | 20% elemental Ca      | 0.100   | 814-80-2  | Food grade; provides ≈400mg Ca per pouch                        |
| Sodium Chloride (NaCl)             | 3.5                 | ≥99.5% food grade     | 0.005   | 7647-14-5   | Common salt; dietary sodium; electrolyte balance                |
| Mixed tocopherols ( 50% active)    | 30.00               |                       | 0.050   | (( $\alpha$ : $\beta$ : $\gamma$ : $\delta$ ) =1.0:0.3:6.0:2.0) | GRAS stabilizer   |
| Anti-caking carrier (q.s.)         | 16.5                | Food grade            | 0.100   | Various   | Silicon dioxide, Maltodextrin; GRAS; flow aid; q.s. to 100.000g |
| <b>Protein Quality Parameters</b>  |                     |                       |         |   |   |
| Total crude protein (Nx6.25)       | % w/w               | ≥ 65.0                | —       | Kjeldahl or Com-bustion   | On dry basis  |
| Fat content                        | % w/w               | 8.0 to 12.0           | —       | Soxhlet or NMR  |   |
| Ash content                        | % w/w               | ≤ 8.0                 | —       | AOAC 942.05   |   |
| Calcium (total)                    | mg / 100 g          | 400 ± 50              | —       | ICP OES   | Primary from Ca-lactate   |
| Phosphorus (total)                 | mg / 100 g          | 400 to 600            | —       | ICP OES   | From protein sources  |
| <b>Functional Properties</b>       |                     |                       |         |   |   |
| Solubility in water                | %                   | ≥ 90                  | —       | Centrifuge method   | At pH 6.8, 20°C   |
| Emulsification capacity            | —                   | Good                  | —       | Visual/functional test  | Stable emulsion formation                                       |
| Gel strength (post-retort)         | —                   | Moderate              | —       | Texture analyzer  | Slurry consistency target                                       |
| <b>Microbiology</b>                |                     |                       |         |   |   |
| Total aerobic plate count (TPC)    | cfu g <sup>-1</sup> | ≤ 5 × 10 <sup>4</sup> | —       | ISO 4833 Plate count  |   |
| Yeast and mould                    | cfu g <sup>-1</sup> | ≤ 1 × 10 <sup>3</sup> | —       | ISO 21527 Plate count   |   |
| Salmonella spp.                    | per 25 g            | Not detected          | —       | ISO 6579 Enrichment   |   |
| Enterobacteriaceae                 | cfu g <sup>-1</sup> | ≤ 1 × 10 <sup>3</sup> | —       | ISO 21528   |   |
| E. coli                            | cfu g <sup>-1</sup> | ≤ 10                  | —       | ISO 16649   |   |
| <b>Contaminants and Safety</b>     |                     |                       |         |   |   |

| Parameter                             | Unit                                   | Spec                                 | CAS No.   | Method / Instru-<br>ment  | Result /<br>Comments      |
|---------------------------------------|--|--------------------------------------|-----------|---------------------------|---------------------------|
| Heavy metals (Pb)                     | mg kg <sup>-1</sup>                    | ≤ 0.5                                | 7439-92-1 | ICP MS                    |                           |
| Heavy metals (Cd)                     | mg kg <sup>-1</sup>                    | ≤ 0.2                                | 7440-43-9 | ICP MS                    |                           |
| Aflatoxin (total)                     | μg kg <sup>-1</sup>                    | ≤ 10                                 | Various   | LC-MS/MS                  |                           |
| Melamine                              | mg kg <sup>-1</sup>                    | Not de-<br>tected<br>or Below<br>LOQ | 108-78-1  | LC-MS/MS                  |                           |
| <b>Allergen Declaration</b>           |  |                                      |           |                           |                           |
| Milk (whey)                           | —                                      | Present<br>(declared<br>allergen)    | —         | Label declaration         |                           |
| Egg                                   | —                                      | Present<br>(declared<br>allergen)    | —         | Label declaration         |                           |
| Soy                                   | —                                      | Present<br>(declared<br>allergen)    | —         | Label declaration         |                           |
| <b>Physical and Stability</b>         |  |                                      |           |                           |                           |
| Bulk water activity (a <sub>w</sub> ) | —                                      | ≤ 0.65                               | —         | Aqualab or<br>Rotronic    |                           |
| Peroxide value                        | meq O <sub>2</sub><br>kg <sup>-1</sup> | ≤ 5.0                                | —         | AOCS Cd 8b-90             | For lipid content         |
| <b>Packaging and Storage</b>          |  |                                      |           |                           |                           |
| Primary packaging                     | —                                      | Food-<br>grade<br>sealed<br>pouches  | —         | Visual                    | Per 6500g pre-<br>weighed |
| Secondary packaging                   | —                                      | Corrugated<br>box with<br>desiccant  | —         | Visual                    |                           |
| Storage conditions                    | —                                      | Store dry,<br>10–20°C,<br>RH < 60%   | —         | Visual or log             |                           |
| <b>Acceptance</b>                     |  |                                      |           |                           |                           |
| Sample size for incoming QC           | —                                      | 1 pouch<br>per 10<br>boxes           | —         | QA plan                   |                           |
| Release decision                      | —                                      | Accept or<br>Reject or<br>Hold       | —         | QA manager sig-<br>nature |                           |
| <b>Sign off</b>                       |  |                                      |           |                           |                           |
| Checked by (incoming QC)              | Name/Sign                              | Date                                 | —         | Comments                  |                           |
| Approved by (QA Manager)              | Name/Sign                              | Date                                 | —         | Comments                  |                           |

Table 8.4: DogCorePro Composition (per 10 kg run = 100 wet food pouches)

| Component                      | Dose per 10 kg   | Per pouch |
|--------------------------------|--|-----------|
| DogCore Premix (Current spec)  | 6500g  | 65g       |
| DogPro Premix                  | 100 g  | 1.0 g     |
| Mixed tocopherol liquid Premix | 100 ml   | 1.0 ml    |
| Palatant Liquid Premix         | 100ml  | 1.0ml     |
| Omega-3 Fish Oil PV<=5.0meq/Kg | 250ml  | 2.50ml    |
| Rendered Bone Broth            | 4200ml   | 42.0ml    |
| Nett Weight per pouch          | 112.5g pre-retort 101.5g $\pm$ 0.50; declared weight 100.00g |           |

## Composition for DogCorePro

### Composition Notes:

- **DogCore Premix:** Provides high quality protein powders and Calcium to be paired 1:1 with CatCorePro meat pouches.
- **DogCore Premix Usage:** 6.5 Kg per 10 kg production run of DogCore or 65.0 g per 100 g wet food pouch.
- **DogPro Premix:** Complements DogCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **AAFCO Compliance:** Together DogCore and DogPro meets AAFCO requirements for complete and balanced nutrition when paired with CatCore and CatPro as per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking. Ca:P  $\geq$ 1.4:1 within AAFCO recommended limits when paired with CatCorePro pouches as per diet chart.
- **Antioxidant Premix:** Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Omega-3 Fish Oil Blend:** Provides omega 3:omega 6 balance
- **Palatant Premix:** Meat Hydrolysates for enhanced palatability.
- 
- **Rendered Bone Broth:** Solvent base for retort processing; improves hydration, adds collagen, chondroitin and other bone joint stability nutrients.
- **NO Alginate Gel - Ca Premix:** No alginate gel in this SKU. Forms slurry consistency.
- **Low Sodium:** DogCore provides  $\approx$  14.0 mg Na per 100g wet food. Palatant Premix provides additional 47.0mg Na to meet electrolyte balance requirements ( $\approx$  0.061% Na w/w) as per AAFCO when paired with CatCorePro pouches as per diet chart.

## COA and Incoming QC - DogPro v5 (100 g premix packet) with ORANGE Sticker

All weights are expressed in grams (g) per 100 g premix formulation. Carrier (q.s.) to reach 100 g

Table 8.5: DogPro v5 Premix Composition COA and Incoming QC (per 100 g premix)

| Parameter  | Unit               | Spec                       | CAS No.         | Method / Instru-<br>ment   | Result /<br>Comments               |
|--|--------------------|----------------------------|-----------------|----------------------------|------------------------------------|
| <b>Identification and Batch</b>                                  |                    |                            |                 |                            |                                    |
| Product name or code   | —                  | DogPro v5 (100 g packet)   | —               | Visual label check         |                                    |
| Color Coded ORANGE Sticker                                       | —                  | Orange                     | —               | Visual                     |                                    |
| Lot or Batch number  | —                  | Supplier lot present       | —               | Visual                     |                                    |
| Manufacture date   | —                  | Present                    | —               | Visual                     |                                    |
| Expiry or Best before  | —                  | Present                    | —               | Visual                     |                                    |
| <b>Physical and Packaging</b>                                    |                    |                            |                 |                            |                                    |
| Net packet mass  | g                  | 100.00 ± 0.20              | —               | Analytical balance (tare)  |                                    |
| Appearance   | —                  | Free flowing, no caking    | —               | Visual inspection          |                                    |
| Odour  | —                  | Characteristic, not rancid | —               | Sensory                    |                                    |
| Color  | —                  | Off white to pale beige    | —               | Visual                     |                                    |
| Particle size (D90)  | μm                 | ≤ 250                      | —               | Sieve or laser diffraction |                                    |
| Bulk density   | g mL <sup>-1</sup> | 0.40 to 0.65               | —               | Volumetric fill test       |                                    |
| Moisture (LOD)   | % w/w              | ≤ 4.0                      | —               | AOAC 925.10 (LOD)          |                                    |
| <b>Composition (assay) - key actives per 100 g premix packet</b> |                    |                            |                 |                            |                                    |
| Component  | Quantity (g)       | Assay/Grade                | Tolerance ± (g) | CAS Number                 | Supplier Specification             |
| Choline chloride   | 20.000             | 60% assay                  | 0.200           | 67-48-1                    | USP/FCC grade; free-flowing powder |
| Taurine  | 10.000             | ≥99% purity                | 0.200           | 107-35-7                   | USP grade; pharmaceutical quality  |
| Inulin (chicory root)  | 12.000             | FOS ≥90%                   | 0.200           | 9005-80-5                  | Prebiotic fiber; food grade        |
| Magnesium gluconate  | 10.000             | USP grade                  | 0.100           | 3632-91-5                  | Dihydrate form; food grade         |
| L-Carnitine tartrate   | 7.500              | ≥98% L-carnitine           | 0.100           | 36687-82-8                 | 2:1 L-carnitine:tartrate ratio     |
| Glucosamine HCl  | 6.000              | ≥98% purity                | 0.100           | 66-84-2                    | Joint support; USP/food grade      |

| Parameter                                    | Unit  | Spec                                     | CAS No. | Method / Instru-<br>ment | Result / Com-<br>ments                 |
|--|-------|--|---------|--------------------------|--|
| Betaine (TMG)                                | 6.000 | ≥98% pu-<br>rity                         | 0.100   | 107-43-7                 | Anhydrous; food<br>grade               |
| Potassium citrate                            | 5.000 | Tripotassium<br>citrate<br>food<br>grade | 0.100   | 866-84-2                 | Monohydrate;<br>USP/FCC                |
| Collagen peptides                            | 5.000 | Hydrolysed<br>bovine                     | 0.100   | 9064-67-9                | Low molecular<br>weight; food<br>grade |
| MSM (Methylsulfonylmethane)                  | 4.000 | ≥99% pu-<br>rity                         | 0.100   | 67-71-0                  | Sulfur donor; food<br>grade            |
| DL-Methionine                                | 3.500 | USP grade<br>≥98.5%                      | 0.050   | 59-51-8                  | Free amino acid<br>form                |
| Zinc bisglycinate chelate                    | 3.00  | 25% el-<br>emental<br>Zn                 | 0.0500  | 14281-83-5               | Chelated form;<br>GRAS                 |
| Iron proteinate                              | 2.00  | 20% el-<br>emental<br>Fe                 | 0.050   | 9007-73-2                | Chelated organic<br>form               |
| Vitamin K <sub>2</sub> (MK-7)                | 1.700 | 1.0%<br>menaquinone-<br>7 assay          | 0.050   | 2124-57-4                | Spray-dried;<br>≥1.0% MK-7             |
| Selenium yeast                               | 0.550 | 0.20% ele-<br>mental Se                  | 0.050   | Various                  | Organic selenium;<br>food grade        |
| L-Cysteine                                   | 0.500 | USP grade<br>≥98%                        | 0.050   | 52-90-4                  | Free base or HCl<br>form               |
| Niacin (B <sub>3</sub> )                     | 0.250 | ≥99% pu-<br>rity                         | 0.020   | 59-67-6                  | Nicotinic acid or<br>niacinamide       |
| Copper proteinate                            | 0.200 | 10% el-<br>emental<br>Cu                 | 0.020   | 9007-73-2                | Chelated organic<br>form               |
| Thiamine HCl (B <sub>1</sub> )               | 0.190 | ≥99% pu-<br>rity                         | 0.020   | 67-03-8                  | Hydrochloride<br>form; USP             |
| Manganese proteinate                         | 0.150 | 10% el-<br>emental<br>Mn                 | 0.020   | 9007-73-2                | Chelated organic<br>form               |
| Vitamin D <sub>3</sub>                       | 0.115 | 100000<br>IU/g chole-<br>calciferol      | 0.005   | 67-97-0                  | Spray-dried; sta-<br>bilized           |
| Vitamin E (dl- $\alpha$ -tocopheryl acetate) | 0.065 | 400 IU/g                                 | 0.005   | 7695-91-2                | Antioxidant; retort<br>overage         |
| Riboflavin (B <sub>2</sub> )                 | 0.050 | ≥98% pu-<br>rity                         | 0.010   | 83-88-5                  | USP grade; fine<br>powder              |
| Pyridoxine HCl (B <sub>6</sub> )             | 0.050 | ≥98% pu-<br>rity                         | 0.010   | 58-56-0                  | Hydrochloride<br>form; USP             |



| Parameter                             | Unit                                | Spec                           | CAS No.  | Method / Instru-<br>ment | Result / Com-<br>ments                          |
|---------------------------------------|-------------------------------------|--------------------------------|--|--------------------------|---|
| Vitamin A palmitate                   | 0.040                               | 320000 IU/g retinyl palmitate  | 0.004  | 79-81-2                  | Spray-dried; stabilized                         |
| Potassium iodate                      | 0.015                               | $\geq 99.5\%$ KIO <sub>3</sub> | 0.002  | 7758-05-6                | Food grade; iodine source                       |
| D-Biotin (B <sub>7</sub> )            | 0.008                               | $\geq 98\%$ purity             | 0.002  | 58-85-5                  | Pharmaceutical grade; crystalline               |
| Mixed tocopherols (50% active powder) | 1.000                               | 0.050                          | (( $\alpha$ : $\beta$ : $\gamma$ : $\delta$ ) = 1.0:0.3:6.0:2.0) GRAS stabilizer |                          |   |
| Anti-caking carrier (q.s.)            | 1.000                               | Food grade                     | 0.100  | Various                  | Silicon dioxide, Maltodextrin; q.s. to 100.000g |
| <b>Microbiology</b>                   |                                     |                                |  |                          |   |
| Total aerobic plate count (TPC)       | cfu g <sup>-1</sup>                 | $\leq 1 \times 10^4$           | —  | ISO 4833 Plate count     |   |
| Yeast and mould                       | cfu g <sup>-1</sup>                 | $\leq 1 \times 10^3$           | —  | ISO 21527 Plate count    |   |
| Salmonella spp.                       | per 25 g                            | Not detected                   | —  | ISO 6579 Enrichment      |   |
| Enterobacteriaceae                    | cfu g <sup>-1</sup>                 | $\leq 1 \times 10^3$           | —  | ISO 21528                |   |
| <b>Contaminants and Safety</b>        |                                     |                                |  |                          |   |
| Heavy metals (Pb)                     | mg kg <sup>-1</sup>                 | $\leq 0.5$                     | 7439-92-1  | ICP MS                   |   |
| Heavy metals (Cd)                     | mg kg <sup>-1</sup>                 | $\leq 0.2$                     | 7440-43-9  | ICP MS                   |   |
| Aflatoxin (total)                     | $\mu\text{g kg}^{-1}$               | $\leq 10$                      | Various  | LC-MS/MS                 |   |
| Melamine                              | mg kg <sup>-1</sup>                 | Not detected or Below LOQ      | 108-78-1   | LC-MS/MS                 |   |
| <b>Physical and Stability</b>         |                                     |                                |  |                          |   |
| Bulk water activity (a <sub>w</sub> ) | —                                   | $\leq 0.60$                    | —  | Aqualab or Rotronic      |   |
| Peroxide value (if oil)               | meq O <sub>2</sub> kg <sup>-1</sup> | $\leq 5.0$                     | —  | AOCS Cd 8b-90            | NA for dry premix                               |
| <b>Packaging and Storage</b>          |                                     |                                |  |                          |   |
| Packet seal integrity                 | —                                   | No leaks, hermetic seal        | —  | Vacuum or visual         |   |
| Pouch labelling                       | —                                   | Lot, Mfg date, Expiry, COA     | —  | Visual                   |   |
| Storage conditions                    | —                                   | Store dry, 10–20°C, RH < 60%   | —  | Visual or log            |   |

| Parameter                   | Unit          | Spec                           | CAS No. | Method / Instru-<br>ment  | Result /<br>Comments |
|-----------------------------|---------------|--------------------------------|---------|---------------------------|----------------------|
| <b>Acceptance</b>           |               |                                |         |                           |                      |
| Sample size for incoming QC | —             | 1 packet<br>per 10<br>boxes    | —       | QA plan                   |                      |
| Release decision            | —             | Accept or<br>Reject or<br>Hold | —       | QA manager sig-<br>nature |                      |
| <b>Sign off</b>             |               |                                |         |                           |                      |
| Checked by (incoming QC)    | Name/SignDate |                                | —       | Comments                  |                      |
| Approved by (QA Manager)    | Name/SignDate |                                | —       | Comments                  |                      |

**Premix Composition Notes:**

- **DogPro Premix:** Complements DogCore Protein-Ca Premix with complete essential vitamins, minerals and chelators and adequate retort loss overage.
- **Useage:** 100 g DogPro Premix per 10 kg production run of DogCore or 1.0 g per 100 g wet food pouch.
- **AAFCO Compliance:** Together DogCore and DogPro meets AAFCO requirements for complete and balanced nutrition when paired with CatCore and CatPro as per diet chart.
- **Design Overages:** Enhanced taurine formulation for cardiac health support. Vitamin A is balanced carefully with daily 4.0g fresh liver from 2 CatCore pouches to avoid stacking.
- **Antioxidant Premix:** 100ml per 10Kg run or 1ml per 100g wet food pouch. Provides Primary Vitamin E (dl- $\alpha$ -tocopheryl) and mixed antioxidants for enhanced oxidative stability.
- **Omega-3 Fish Oil Blend:** Omega-3 Fatty Acid Fish Oil PV $\leq$ 5.0meq/Kg is added at 250ml per 10Kg run or 2.5ml per per 100g wet food pouch except sardine SKU.
- **Palatant Premix:** 100ml per 10Kg run or 1ml per 100g wet food pouch.
- **NO Alginate Gel - Ca Premix:** No alginate gel in this SKU. Forms slurry consistency.

**Alginate Gel — Encapsulated Ca Premix COA**

| Field                                  | Specification / Result / Method   |
|--|---|
| <b>Product identity</b>                | Gel / Alg-Um Premix — free-flowing light-beige powder; gel-forming and texture-binding premix for broth phase.<br>Packet mass: 100.000000 g (use 1 packet per 10 kg run = 1 g/pouch).                     |
| <b>Composition (per 100 g packet)</b>  | Sodium alginate ... 60.000000 g (viscosity 200—300 cP @ 1%)<br>Encapsulated Ca-lactate catalyst ..39.500000 g (20% available Ca)<br>Anti-caking (carrier q.s) ..... 0.500000 g                            |
| <b>Analytical specifications</b>       | Moisture $\leq 6\%$ ; pH (1% solution) 6.0–7.5; Bulk density 0.45—0.55 g/mL.<br>Gel strength 300—400 g/cm <sup>2</sup> (Bloom); Viscosity 200—300 cP (1% solution); Film clarity $\geq 85\%$ .            |
| <b>Contaminants &amp; microbiology</b> | Pb $\leq 2$ mg/kg; Cd $\leq 1$ mg/kg; As $\leq 2$ mg/kg; Hg $\leq 0.1$ mg/kg (ICP-MS).<br>TPC $\leq 10^3$ CFU/g; Yeasts&moulds $\leq 10^2$ CFU/g; *E. coli* / *Salmonella* absent; Mycotoxins ND.         |
| <b>Functional performance</b>          | Retort stability: no separation after 121 °C $\times$ 20 min; Gel strength retention $\geq 90\%$ .<br>pH shift post-retort $\Delta$ pH $\leq 0.3$ ; Color stability $\Delta E \leq 3$ .                   |
| <b>Origin &amp; compliance</b>         | Alginate: non-GMO *Laminaria digitata* extract; Fish hydrolysate: food-grade marine by-products (PV < 5).<br>Conforms to EU 2015/786 and AAFCO 73.350; Non-GMO; BSE/TSE-free.                             |
| <b>COA traceability / checksum</b>     | Supplier ID .....ALGUM-<supplier-id><br>Lot / Batch .....<lot-no><br>Assay date ..... YYYY-MM-DD<br>COA Hash (SHA-256) <sha256:algum lot gelstrength viscosity moisture><br>Valid until ..... YYYY-MM-DD. |
| <b>Usage &amp; dosing</b>              | Use 1 packet (100 g) per 10 kg run $\rightarrow$ 1 g per pouch; add during liquid pre-blend for gel formation.  |
| <b>Storage &amp; shelf-life</b>        | Store sealed, dry (< 25 °C, RH < 60%); Shelf life = 12 months; reject if viscosity < 180 cP.  |
| <b>Remarks / QA notes</b>              | Verify gel strength on receipt; confirm Ca encapsulation integrity; record COA hash before use.   |

**COA — Antioxidant Liquid Premix for all SKUs (100 ml)**

| Field                                  | Specification / Result / Method  |
|--|--|
| <b>Product identity</b>                | Palatant-Antioxidant Liquid Premix — Amber liquid with enhanced antioxidant system for all SKUs; mild savory aroma.<br><i>Packet volume:</i> 100.000000 ml (use 1 bottle per 10 kg wet food production run = 1 ml per 100 g pouch).  |
| <b>Composition (per 100 ml bottle)</b> | Rosemary extract ..... 28.000000 ml (primary antioxidant)<br><br>Sunflower lecithin (food-grade) .... 27.000000 ml (phospholipid emulsifier)<br>Grape seed extract concentrate ..... 24.000000 ml (proanthocyanidins, antioxidant synergy)<br>Citric acid aqueous solution (25% w/v) 10.000000 ml (pH buffer, chelator)<br>Mixed tocopherols ( $\alpha : \beta : \gamma : \delta = 1.0:0.3:6.0:2.0$ ) .. 10.000000 ml (Vit E source)<br>Glycerol monostearate (GMS, q.s.) ..... 1.000000 ml (emulsifier carrier)   |
| <b>Analytical specifications</b>       | Appearance: Amber to dark amber viscous liquid; Odor: Mild savory with herbal note, no rancidity.<br>Viscosity (25 deg C): 60-180 mPa·s (Brookfield viscometer).<br>Moisture (Karl Fischer): $\leq 0.3\%$ ; pH (1% solution): 5.0-6.5 (citric acid adjusted).<br>Peroxide value (PV): $\leq 3.0$ meq O <sub>2</sub> /kg (AOCS Cd 8b-90, stricter for high-PUFA).<br>Anisidine value: $\leq 15$ (AOCS Cd 18-90).<br>Vitamin E (dl- $\alpha$ -tocopherol equiv): $\approx 8$ IU per 100 g wet food pouch (post-retort with 20% loss).<br>Total polyphenols (grape seed): $\geq 80$ mg GAE per 100 ml (Folin-Ciocalteu method). |
| <b>Microbiology</b>                    | Total plate count (TPC): $\leq 1 \times 10^3$ cfu/ml (ISO 4833).<br>Yeast and mould: $\leq 1 \times 10^2$ cfu/ml (ISO 21527).<br><i>Salmonella</i> spp.: Not detected per 25 ml (ISO 6579).<br><i>E. coli</i> : Absent per 10 ml.  |
| <b>Contaminants &amp; safety</b>       | Pb $\leq 2$ mg/kg; Cd $\leq 1$ mg/kg; As $\leq 2$ mg/kg; Hg $\leq 0.1$ mg/kg (ICP-MS).<br>Histamine: $\leq 50$ mg/kg; Mycotoxins: ND (not detected).<br>Pesticide residues: ND; 3-MCPD/GEs: $\leq 1$ mg/kg.<br>Citric acid: Food-grade, non-GMO; Complies with E330 specification.   |
| <b>Functional performance</b>          | Oxidative stability (Rancimat at 110 deg C): $\geq 10$ hours (enhanced vs Palatant A).<br>Emulsification index: $\geq 90\%$ ; Volatile loss after retort: $\leq 8\%$ .<br>Palatability index: $\geq +20\%$ feed intake (vs control, cat/dog panel n = 20).<br>Color stability: $\Delta E \leq 4$ post-retort (grape seed may darken slightly).<br>PUFA protection: TBARS reduction $\geq 70\%$ vs control after 6-month storage.   |
| <b>Origin &amp; compliance</b>         | Rosemary extract: Food-grade, non-GMO (EU approved E392).  |

*Note: 100 ml provides organic extracts, mixed tocopherols, lecithin, antioxidants and dietary Vit E for both CatCore and DogCore lines.*

*Omega-3 Fish Oil — Pre-stabilised, Shelf-Stable (Low PV / Low Hg)*

- **Product type:** Refined and deodorised marine triglyceride oil (fish origin, e.g. sardine / anchovy / menhaden).
- **Function:** Energy enrichment and EPA/DHA source for feline wet diets; provides omega-3 balance and improved skin-coat nutrition.
- **Dosage:** 250 mL per 10 kg production run ( $\approx 2.5$  mL per 100 g pouch,  $\approx 2.3$  g oil/pouch).
- **Packaging:** 250 mL amber HDPE bottles; minimum order 1.5 L (6  $\times$  250 mL). Nitrogen-flushed and induction-sealed.
- **Composition:**
  - Total omega-3 (EPA + DHA)  $\geq 30$  % of fatty acids ( $\geq 300$  mg/g oil).
  - Triglyceride form  $\geq 90$  %.
  - Antioxidant system: mixed tocopherols 0.05 – 0.10 %; optional rosemary extract  $\leq 0.02$  %.
  - No synthetic flavour, colour, or added stabilisers beyond tocopherols/rosemary.
- **Quality parameters:**
  - Peroxide value (PV)  $\leq 2$  meq O<sub>2</sub> kg<sup>-1</sup>.
  - p-Anisidine value (AV)  $\leq 10$ .
  - Totox (2  $\times$  PV + AV)  $\leq 14$ .
  - Moisture  $\leq 0.05$  %.
  - Acid value  $\leq 1$  mg KOH g<sup>-1</sup>.
  - Heavy metals: mercury < 0.05 ppm, lead < 0.1 ppm, arsenic < 0.1 ppm, cadmium < 0.05 ppm.
  - PCB + dioxin < 0.09 pg TEQ g<sup>-1</sup>.
- **Physical:** Clear, light-gold liquid; density  $0.92 \pm 0.02$  g mL<sup>-1</sup> at 25 °C; no precipitate or clouding  $\geq 10$  °C.
- **Shelf life:** 12 months sealed at  $\leq 25$  °C; 18 months refrigerated (4 °C). Protect from light and air.
- **Microbiology:** Not applicable (oil matrix, sterile by refining).
- **Thermal compatibility:** Stable at 45 °C for 30 min; withstands retort in emulsion form without visible phase separation.
- **Sensory:** Neutral odour and taste; no rancid or fishy off-note; colour Lovibond  $\leq 5Y$ ,  $\leq 0.5R$ .
- **Label declaration:** “Fish oil (pre-stabilised with natural tocopherols and rosemary).”
- **Supplier CoA must report:** PV, AV, Totox, EPA %, DHA %, acid value, moisture, heavy-metal panel, antioxidant %, and bottling date.

*Palatant — Meat Hydrolysate Liquid (Thermostable, Shelf-Stable)*

- **Product type:** Enzymatically hydrolysed poultry or marine protein concentrate, liquid form.
- **Function:** Palatability enhancer and omega-3 odour mask for wet feline diets.
- **Dosage:** 100 mL per 10 kg production run ( $\approx 1$  mL per 100 g pouch).
- **Physical form:** Homogeneous brown liquid; viscosity 1–3 Pa·s at 25 °C; density  $1.05 \pm 0.05$  g mL<sup>-1</sup>.
- **Composition:**
  - Hydrolysed animal protein  $\geq 45$  % (dry basis).
  - Peptides  $< 3$  kDa  $\geq 60$  % of protein fraction.
  - Sodium  $\leq 2$  %.
  - Moisture 45–55 %.
  - Shelf-stable antioxidant system: Rosemary extract 0.10 %.
  - Preservative: potassium sorbate 0.10 %.
  - Emulsifier: Glycerol monostearate GMS 0.1%
  - pH 5.5 – 6.5 (as supplied).
- **Thermal stability:** Withstands retort (121 °C  $\times$  30 min) without phase separation or burnt odour.
- **Shelf life:** 12 months at  $\leq 25$  °C; 18 months refrigerated (4 °C); store sealed, away from light and air.
- **Microbiological limits:**
  - Total plate count  $< 10^3$  cfu g<sup>-1</sup>.
  - Yeast & mould  $< 10^2$  cfu g<sup>-1</sup>.
  - Pathogens absent.
- **Additives not permitted:** no synthetic flavour, colour, or MSG.
- **Sensory:** Rich meaty aroma; no rancid or sulphidic notes.
- **Label declaration:** “Natural meat(non-poultry) hydrolysate (palatant).”
- **Supplier CoA must include:** protein %, Na %, preservative %, moisture %, pH, microbiology, retort-stability report.

## Chapter 9

# Standard Operating Procedures

### SOP 30-A — Retort Line Floor Operations For CatCore SKUs

**Batch Size:** 10 kg run = 100 pouches × 100.00 g declared weight, target 100.5g /*pm* 0.5g

**Premix Dosing:** Color-coded QC verification required. CatCore system uses RED stickers for Premix. Refer to SOP 30-B for DogCore SKU.

**Target Calories:** CatCore 100-110 kcal/100g

**Total Production Time:** Approximately 7-8 hours (single production day) with 2 work benches for parallel processing to optimise time, pathogen load and flavor profile.

**Reference:** For detailed QC tolerances, assay protocols, and audit trails, see the detailed SOP binder. This document is for line cooks and supervisors on the shop floor.

#### Mass Balance Summary (per 100 pouches)



Table 9.1: Mass Balance for 10 kg Production Run (100 pouches)

| Component   | Per Pouch (g)  | Per Batch (kg)       | Notes                                   |
|---|----------------|----------------------|---|
| <i>SOLID PHASE</i>  |                |                      |   |
| Raw solids (per SKU BOM)  | 65.0           | 6.500                | As specified in SKU formulation         |
| Water absorption during blanch  | +2.0           | +0.200               | Approximately 3% weight gain            |
| Blanched solids (net)   | 67.0           | 6.700                | Ready for marination                    |
| <i>TOTAL LIQUID PHASE</i>   |                |                      |   |
| Bone broth (gelatinous base)  | 40.0           | 4.000                | From initial 4.10 kg total, set aside 0 |
| Blanch Water recovery   | 2.5            | 0.250                | Recovered from blanching                |
| Liquid Palatant   | 1.0            | 0.10                 | Addition of Liquid Palatant - Antioxi   |
| Broth Liquid Total  | 43.5           | 4.350                | Split into TWO BROTH SYSTEM             |
| <i>LIQUID PHASE — Broth A (Premix carrier)</i>                                    |                |                      |   |
| Bone broth (base)   | 10.0           | 1.000                | From initial 4.10 kg total              |
| CatPro premix   | 1.0            | 0.100                | Color-coded packet                      |
| Blanch water recovery   | 2.5            | 0.250                | Recovered from blanching                |
| Broth A subtotal  | 12.5           | 1.250                | For marination                          |
| <i>LIQUID PHASE — Broth B (Gel system)</i>  |                |                      |   |
| Bone broth (base)   | 31.0           | 3.100                | From initial 4.10 kg total              |
| Alginate-Ca premix  | 1.0            | 0.100                | Added just before filling               |
| Broth B subtotal  | 32.0           | 3.200                | Gel injection phase                     |
| <b>Phase 1 Fill (Solids + Broth A)</b>  | <b>80.5</b>    | <b>8.050</b>         | First fill (scale tared)                |
| <b>Phase 2 Fill (Broth B + Gel)</b>   | <b>32.0</b>    | <b>3.300</b>         | Second fill (injected)                  |
| <b>PRE-RETORT TOTAL (food only)</b>   | <b>112.5</b>   | <b>11.250</b>        | Target before sealing                   |
| <i>Palatant-Antioxidant A/B (distributed in broth) — Included in broth totals</i> |                |                      |   |
| <i>RETORT PROCESS</i>   |                |                      |   |
| Moisture loss during retort (–10%)  | –11.25         | –1.125               | Water evaporates                        |
| <b>POST-RETORT FOOD WEIGHT</b>  | <b>101.0</b>   | <b>10.100</b>        | Actual food content                     |
| <i>FINAL PRODUCT</i>  |                |                      |   |
| Declared food weight  | 100.0          | 10.000               | Label claim                             |
| Pouch tare weight   | +4.0           | +0.400               | Empty pouch material                    |
| <b>Final packaged weight (QC target)</b>  | <b>104–105</b> | <b>10.400–10.500</b> | Post-retort scale reading               |

## Line Supervisor Pre-Production Checklist

**Complete this checklist before starting production. All items must be checked and signed off.**

- Prepare Timesheet. Timesheet should have Start time, End time, Target Duration and Actual Duration for each step, Sign off to next step.  
Confirm premix Certificates of Analysis (COAs) are current and QC-approved  
Verify batch weights for all premixes, solids, and broth match Bill of Materials (BOM)  
Assemble pre-production items:
  - Retort pouches (100 units QC checked + 10 spares).
  - Labels and batch markers
  - Calibrated pH meters (QC sign-off required)
  - Calibrated scales (QC sign-off required)
  - Calibrated thermometers and sensors (QC sign-off required)
 Confirm color-coded premix packets match production schedule:
  - **RED sticker** = CatPro (all CatCore SKUs)
  - Verify Palatant-Antioxidant variant: A (Standard - RED STICKER) or B (Sardine SKU- BLUE STICKER)
 Prepare production log forms and batch record sheets  
Obtain all equipment calibration sign-offs from QC before production start
- Assemble all empty pouches in filling line prior to handling food materials to ensure short handling time.  
This ensures control of pathogen load and flavor profile.

**Supervisor Sign-Off:** \_\_\_\_\_ **Date:** \_\_\_\_\_

**QC Sign-Off:** \_\_\_\_\_ **Date:** \_\_\_\_\_

### Step 1: Liquid Phase Preparation

**Estimated Time:** 15—20 minutes (operator active)

**Personnel Required:** 1 operator

**Equipment Required:** Heating vessel, paddle mixer, calibrated pH meter, thermometer

#### Day before production:

1. Render bone broth overnight (minimum 12 hours) and skim if needed. Sieve in fine mesh to remove grit.
2. Chill broth to 4 °C . Maintain Cold Chain Logs. Discard if more than 24 hours.
3. Store covered until production day

#### On retort day:

**Log Start Time in Timesheet:** \_\_\_\_ Measure **4.10 kg bone broth** and transfer 4.00 Kg to heating vessel.

Set aside 0.10Kg for evaporation loss and ops error. Slowly warm 4.00 Kg Broth to 25 °C while gently stirring (3—5 min) **pH Check #1:**

6. • Target: pH 6.4—6.5 (5 min)
  - Use calibrated pH meter
  - If outside range, adjust with food-grade acid/base (5 min)
  - **Obtain QC sign-off before proceeding**
7. Continue warming to 40 °C while stirring (10 min)
8. **Add 100 ml Palatant-Antioxidant premix (2 min):**

**CRITICAL STEP — CANNOT BE SKIPPED**

**Purpose:** Protects solids from oxidation during processing, provides palatability enhancement, and supplies primary Vitamin E

- **Premix A (standard antioxidant - RED STICKERS):** Use for Heart, Liver, Gizzard, Spleen, Kidney SKU
- **Premix B (enhanced antioxidant - BLUE STICKER):** Use for Sardine SKU ONLY

- ✓ Verify bottle label matches production schedule
- ✓ Check color coding on bottle
- ✓ **Obtain supervisor sign-off before adding**

9. Paddle mix for 2—3 minutes until fully dispersed (3 min)
10. **Total liquid: 4.20 kg** (broth + Palatant-Antioxidant)
11. Maintain steady temperature at 40 °C
12. Skim foam if present

**QC Checkpoints:**

- pH 6.4—6.5 (recorded in batch log)
- Temperature 40 °C  $\pm$  2 °C
- Complete dispersion of Palatant (no oil separation) **Log End Time in Timesheet:** \_\_\_\_ **Log Duration:** Target 30—35 minutes. If over this limit, halt and call supervisor. This step is essential to control pathogen load and flavor profile.

**Step 1A/ Step 2: Solid Phase Preparation and Steam Blanch****SOP 30b — DogCore Retort Line Floor Operations**

**Batch Size:** 10 kg run = 100 pouches  $\times$  100 g declared weight

**Premix Dosing:** Color-coded QC verification required

**Target Calories:** DogCore 240-300 kcal/100g

**Total Production Time:** Approximately 5-6 hours (single production day)

**Reference:** For detailed QC tolerances, assay protocols, and audit trails, see the detailed SOP binder. This document is for line cooks and supervisors on the shop floor.

**Key Difference from CatCore SOP 30-A:** DogCore uses a powder-based formulation with NO alginate gel system. The powder is slowly incorporated into enriched broth to create a custard-like slurry that sets during retort through egg white protein gelation.

**Mass Balance Summary (per 100 pouches)**

Table 9.2: Mass Balance for DogCore 10 kg Production Run (100 pouches)

| Component                                | Per Pouch (g)      | Per Batch (kg) | Notes                           |
|--|--------------------|----------------|---------------------------------|
| <i>LIQUID PHASE</i>                      |                    |                |                                 |
| Bone broth (base)                        | 46.0               | 4.600          | Increased from CatCore          |
| Palatant-Antioxidant A (RED STICKER)     | 1.0                | 0.100          | Standard antioxidant blend      |
| Enriched broth subtotal                  | 47.0               | 4.700          |                                 |
| <i>PREMIX PHASE</i>                      |                    |                |                                 |
| DogPro premix                            | 1.0                | 0.100          | ORANGE sticker                  |
| DogPro-enriched broth                    | 48.0               | 4.800          |                                 |
| <i>POWDER PHASE</i>                      |                    |                |                                 |
| DogCore powder blend                     | 65.0               | 6.500          | YELLOW sticker, added in vortex |
| <b>Total slurry (pre-fill)</b>           | <b>113.0</b>       | <b>11.300</b>  | Single-phase system             |
| <b>Target fill per pouch</b>             | <b>112.5</b>       | <b>11.250</b>  | Scale tared to zero             |
| <i>RETORT PROCESS</i>                    |                    |                |                                 |
| Moisture loss during retort (−10%)       | −11.25             | −1.125         | Water evaporates                |
| <b>POST-RETORT FOOD WEIGHT</b>           | <b>101-102</b>     | <b>10.125</b>  | Actual food content             |
| <i>FINAL PRODUCT</i>                     |                    |                |                                 |
| Declared food weight                     | 100.0              | 10.000         | Label claim                     |
| Pouch tare weight                        | +4.5               | +0.450         | Empty pouch material            |
| <b>Final packaged weight (QC target)</b> | <b>105.5 ± 0.5</b> | <b>10.550</b>  | Post-retort scale reading       |

## Line Supervisor Pre-Production Checklist

**Complete this checklist before starting production. All items must be checked and signed off.**

Confirm premix Certificates of Analysis (COAs) are current and QC-approved  
Verify batch weights for all premixes, powder, and broth match Bill of Materials (BOM)  
Assemble pre-production items:

- Retort pouches (110 units + spares)
- Labels and batch markers
- Calibrated pH meters (QC sign-off required)
- Calibrated scales (QC sign-off required)
- Calibrated thermometers and sensors (QC sign-off required)

Confirm color-coded premix packets match production schedule:

- **ORANGE sticker** = DogPro premix (100 g per batch)
- **YELLOW sticker** = DogCore powder blend (6.50 kg per batch)
- **RED sticker** = Palatant-Antioxidant- A (100 ml per batch)

Verify paddle mixer is capable of vortex mode for powder incorporation

Prepare production log forms and batch record sheets

Obtain all equipment calibration sign-offs from QC before production start

**Supervisor Sign-Off:** \_\_\_\_\_ **Date:** \_\_\_\_\_

**QC Sign-Off:** \_\_\_\_\_ **Date:** \_\_\_\_\_

### Step 1: Liquid Phase Preparation

**Start Time:** \_\_\_\_\_ **End Time:** \_\_\_\_\_ **Duration:** 35-40 minutes

**Estimated Time:** 35-40 minutes (operator active)

**Personnel Required:** 1 operator

**Equipment Required:** Heating vessel, paddle mixer, calibrated pH meter, thermometer

#### Day before production:

1. Render bone broth overnight (minimum 12 hours)
2. Chill broth to 4 deg C and skim fat if needed
3. Store covered until production day

#### On retort day:

4. Measure **4.60 kg bone broth** and transfer to heating vessel (5 min)
  - **Note:** DogCore uses 4.60 kg broth (vs 4.10 kg in CatCore) to compensate for no blanch water recovery and no water absorption during blanching
5. Slowly warm to 25 deg C while gently stirring (10-15 min)
6. **pH Check #1:**
  - Target: pH 6.4-6.5
  - Use calibrated pH meter
  - If outside range, adjust with food-grade acid/base
  - **Obtain QC sign-off before proceeding**

7. Continue warming to 40 deg C while stirring (10 min)
8. **Add 100 ml Palatant-Antioxidant A premix (2 min):**

**CRITICAL STEP - CANNOT BE SKIPPED**

**Purpose:** Protects powder from oxidation during processing, provides palatability enhancement, and supplies primary Vitamin E

- **DogCore uses Palatant-Antioxidant A (RED sticker) ONLY**
  - Standard antioxidant blend 100ml per 10kg Production Run or 1ml per 100g wet food pouch.
- ✓ Verify Antioxidant bottle label shows RED sticker  
✓ Check expiration date  
✓ **Obtain supervisor sign-off before adding**

9. Paddle mix for 2-3 minutes until fully dispersed (3 min)
10. **Total enriched broth: 4.70 kg**
11. Maintain steady temperature at 40 deg C
12. Skim foam if present (2 min)

**QC Checkpoints:**

- pH 6.4-6.5 (recorded in batch log)
- Temperature 40 deg C  $\pm$  2 deg C
- Complete dispersion of Palatant (no oil separation)
- Weight verification: 4.70 kg  $\pm$  0.05 kg

**Step 2: DogPro Premix Addition**

**Start Time:** \_\_\_\_\_ **End Time:** \_\_\_\_\_ **Duration:** 10-12 minutes

**Estimated Time:** 10-12 minutes (operator active)

**Personnel Required:** 1 operator

**Equipment Required:** Paddle mixer, calibrated pH meter, scale

1. Take the **ORANGE-stickered DogPro premix packet** (2 min)
  - Verify ORANGE sticker matches production schedule
  - Check packet is sealed and undamaged
  - Verify expiration date and COA approval
2. **VERIFY: Check production schedule matches ORANGE sticker for DogCore**
3. **Obtain supervisor sign-off on premix selection**
4. Weigh **100 g DogPro premix** precisely (2 min)
5. Add DogPro premix to 4.70 kg enriched broth while paddle mixing (2 min)
6. Mix steadily for 2-3 minutes until complete dispersion (3 min)
  - Ensure no clumps or settling
  - Premix should be fully dissolved
7. **DogPro-enriched broth now: 4.80 kg**
8. **pH Check #2:**
  - Target: pH 6.4-6.5
  - Adjust if needed
  - **Obtain QC sign-off**
9. Maintain at 40 deg C, covered, ready for powder addition

**QC Checkpoints:**

- ORANGE sticker verified and logged
- DogPro premix weight: 100 g  $\pm$  1 g for 10Kg production run.
- pH 6.4-6.5 (recorded in batch log)
- Complete dispersion (no clumps or settling)
- Total weight: 4.80 kg  $\pm$  0.05 kg

### Step 3: DogCore Powder Preparation - CRITICAL STEP

**Start Time:** \_\_\_\_ **End Time:** \_\_\_\_ **Duration:** 10-15 minutes

**Estimated Time:** 10-15 minutes (operator active)

**Personnel Required:** 1 operator

**Equipment Required:** Scale, sieve (optional), storage containers

1. Take **YELLOW-stickered DogCore powder blend** (2 min)
  - Verify YELLOW sticker matches production schedule
  - Check container is sealed and dry
  - Verify expiration date and COA approval
2. **VERIFY: Check production schedule matches YELLOW sticker for DogCore powder**
3. **Obtain supervisor sign-off on powder selection**
4. Weigh **6.50 kg DogCore powder** precisely (5-8 min)
  - Use clean, dry containers
  - Avoid moisture contamination
  - Check for clumping (if clumped, sieve before use)
5. Optional: Sieve powder through 2 mm mesh to break up any clumps (5 min if needed)
6. **Note powder characteristics on batch log:**
  - Color: Should be uniform beige/tan
  - Texture: Free-flowing, no hard clumps
  - Odor: Neutral to meaty, no off-odors
7. Set powder aside in clean, covered container
8. Keep powder at room temperature (do NOT refrigerate - moisture will cause clumping)

#### QC Checkpoints:

- YELLOW sticker verified and logged
- DogCore powder weight: 6.50 kg  $\pm$  0.05 kg
- Visual inspection: uniform color, free-flowing
- Odor check: neutral/meaty, no rancidity
- Moisture check: powder should be dry (no caking)

### Step 4: Vortex Mixing - Powder Incorporation (CRITICAL)

**Start Time:** \_\_\_\_ **End Time:** \_\_\_\_ **Duration:** 25-30 minutes

**Estimated Time:** 25-30 minutes (operator active - CONTINUOUS ATTENTION REQUIRED)

**Personnel Required:** 2 operators (1 for mixing, 1 for powder addition)

**Equipment Required:** High-speed paddle mixer (vortex capability), large mixing vessel

**CRITICAL STEP - PREVENTS PIZZA DOUGH FORMATION****Objective:** Create smooth, pourable custard-like slurry (NOT thick dough)**Key Success Factors:**

- Maintain vortex throughout powder addition
- Add powder SLOWLY in thin, steady stream over 15-20 minutes while maintaining a steady vortex.
- NEVER dump powder in bulk
- Monitor consistency continuously

**If pizza dough forms:** STOP immediately, add 200-300 ml warm broth, remix slowly

1. Out of 4.80Kg DogPro-enriched broth measure and transfer 4.50 kg to large mixing vessel.
2. HOLD-IN-RESERVE 0.30Kg broth mix for final adjustment to pourable consistency.
  - Use vessel with at least 15 L capacity
  - Ensure broth is at 40 deg C  $\pm$  2 deg C
3. Start paddle mixer at HIGH speed to create vortex (1 min)
  - Vortex should reach halfway down vessel
  - Adjust speed if splashing excessively
  - Maintain stable vortex throughout process
4. **Begin powder addition (20-25 min):**
  - Operator 1: Maintains mixer speed and monitors consistency
  - Operator 2: Adds powder in THIN, STEADY stream
  - Target rate: approximately 250-300 g per minute
  - Total time: 20-25 minutes for 6.50 kg powder
5. **Monitor consistency throughout:**
  - **GOOD:** Smooth, pourable slurry (like thick pancake batter)
  - **ACCEPTABLE:** Slightly thick but still pours (like heavy cream)
  - **BAD:** Clumpy, dough-like, does not pour easily
6. If consistency becomes too thick during addition:
  - PAUSE powder addition
  - Add 100-200 ml of the held-in-reserve broth
  - Mix for 1-2 minutes until smooth
  - Resume powder addition at slower rate
7. After all powder added, add all the held-in-reserve 0.30Kg broth and give it a final mix for 2-3 minutes.
  - Ensure complete dispersion
  - No dry powder pockets
  - Smooth, uniform consistency
8. **Final slurry: 11.30 kg** (4.80 kg broth + 6.50 kg powder)
9. Check temperature: Should be 35-40 deg C (mixing generates slight heat)
10. **Final consistency check:**
  - Pour test: Slurry should flow smoothly from ladle
  - Visual: No lumps, uniform color
  - Texture: Custard-like, NOT dough-like

**QC Checkpoints:**

- Vortex maintained throughout (operator log notes)



- Powder addition time: 20-25 minutes (not rushed)
- Final slurry weight: 11.30 kg  $\pm$  0.10 kg. All Hold-in-Reserve broth is completely utilised.
- Consistency: Pourable custard-like slurry (visual + pour test)
- Temperature: 35-40 deg C
- No lumps or dry powder pockets (visual inspection)

**Common Issues & Solutions:**

- **Issue:** Powder added too fast, clumping occurs
  - **Solution:** Stop addition, increase mixer speed, break up clumps, resume slowly
- **Issue:** Slurry becomes too thick (dough-like)
  - **Solution:** Add 100-200 ml warm broth reserve, mix thoroughly, check consistency
- **Issue:** Vortex lost during mixing
  - **Solution:** Increase mixer speed, reestablish vortex before resuming powder addition
- **Issue:** Powder not dispersing (floating on surface)
  - **Solution:** Increase mixer speed, add powder closer to vortex center, slow addition rate

**Step 5: Pouch Filling - Single Phase**

**Start Time:** \_\_\_\_ **End Time:** \_\_\_\_ **Duration:** 50-60 minutes

**Estimated Time:** 50-60 minutes (operator active)

**Personnel Required:** 1-2 operators (2 operators recommended for faster filling)

**Equipment Required:** Filling line, calibrated scale (tared), 100+ pouches, filling ladle or dosing equipment

1. Set up filling line with **100 empty pouches** (plus spares) (10 min)
2. **Tare scale to zero with empty pouch on it** (pouch weight not counted during fill)
3. **Gently stir slurry before filling** to ensure uniform consistency
  - Stir every 10-15 pouches to prevent settling
  - Do NOT over-stir (avoid incorporating air)
4. Fill each pouch with **112.5 g  $\pm$  0.5 g** of DogCore slurry (30-40 min)
  - Manual filling: approximately 30 seconds per pouch
  - With dosing equipment: approximately 15 seconds per pouch
  - **Note:** DogCore slurry is thicker than CatCore, may require wider dosing nozzle
5. **In-line QC: Weigh every 10th pouch (5 min):**
  - Record weight on production log
  - Scale shows: 112-113 g (pouch tared to zero)
  - Target: 112.5 g  $\pm$  0.5 g
  - **If any pouch deviates by  $>0.5$  g, STOP LINE and report to supervisor**
6. Continue until all 100 pouches filled
7. Keep pouches upright and stable on filling rack
8. **Proceed immediately to sealing** (do not let pouches sit - powder may settle)

**QC Checkpoints:**

- Every 10th pouch weight recorded (112-113 g target)
- Visual inspection: no spills, pouches upright, uniform fill level

- Total pouches filled recorded (should be 100)
- No air pockets or voids visible in filled pouches

**Common Issues & Solutions:**

- **Issue:** Slurry settling during filling (heavier at bottom)
  - **Solution:** Gently stir every 10 pouches, increase stirring frequency
- **Issue:** Slurry too thick to dispense smoothly
  - **Solution:** Warm slurry slightly (to 45 deg C max), or use wider nozzle
- **Issue:** Air bubbles in filled pouches
  - **Solution:** Tap pouches gently after filling, or fill more slowly

**Step 6: Seal and Retort**

**Start Time:** \_\_\_\_\_ **End Time:** \_\_\_\_\_ **Duration:** 120 minutes

**Estimated Time:** 120 minutes total (2 hours)

**Breakdown:**

- Sealing: 30-35 minutes (operator active)
- Retort cycle: 75 minutes (mostly waiting)
- Documentation: 5 minutes

**Personnel Required:** 2 operators (1 for sealing, 1 for retort loading)

**Equipment Required:** Nitrogen flush system, heat sealer, retort chamber, temperature monitoring equipment

**Sealing (complete within 10 minutes of final fill):**

1. Use in-line **nitrogen flush** for all pouches (prevents oxidation)
  - **Important:** DogCore powder contains egg whites - oxygen exposure can cause discoloration
2. **Double-seal** each pouch (20-30 min):
  - Seal width: 5 mm × 2 parallel bands
  - Temperature: 180-190 deg C
  - Dwell time: 2.5-3 seconds
  - Approximately 15-20 seconds per pouch
3. **Inspect every seal (10 min):**
  - Reject if wrinkles, incomplete edges, or weak spots detected
  - Set rejected pouches aside for rework or discard
  - **Note:** DogCore slurry is thicker - ensure seal area is clean before sealing
4. All accepted pouches proceed to retort

**Retort process (IDENTICAL TO CATCORE):**

5. Load sealed pouches in retort racks (10 min):
  - Maintain headspace <10 mm between pouches
  - Water immersion or steam-air mode per equipment specification
6. **Retort cycle parameters:**

- Come-up time:  $\leq 10$  minutes
- Hold temperature: **121 deg C**
- Hold time: **45 minutes** (target  $F_0 \geq 12$ )
- Total cycle time: approximately 75 minutes

7. **Temperature monitoring:**

- Record temperature trace continuously
- Monitor heat penetration in center of chamber
- **CRITICAL: Discard entire batch if any pouch  $< 118$  deg C for  $> 5$  minutes**

8. Cool rapidly: **Below 40 deg C within 20 minutes**

9. **Record (5 min):**

- Time/temperature chart
- Any deviations from standard cycle
- Alternative validated  $F_0$  curve if used

10. **Obtain sign-offs from Line Supervisor AND QC Manager**

**QC Checkpoints:**

- All seals inspected and approved
- Retort temperature chart recorded and attached
- Minimum  $F_0$  value achieved (recorded)
- Cooling time recorded (must be  $< 20$  min)

**DogCore-Specific Note:**

- During retort, egg white proteins in DogCore powder will denature and form custard-like gel texture
- This is expected and desired behavior
- Post-retort texture should be firm but sliceable (NOT liquid)

**Step 7: Post-Retort QC (within 1 hour of cooling)**

**Start Time:** \_\_\_\_\_ **End Time:** \_\_\_\_\_ **Duration:** 60 minutes

**Estimated Time:** 60 minutes total

**Breakdown:**

- Visual inspection: 15 minutes
- Weight verification: 10 minutes
- Destructive testing: 10 minutes
- Labeling: 20 minutes
- Documentation: 5 minutes

**Personnel Required:** 2 operators

**Equipment Required:** Calibrated scale, labels, photography equipment (for destructive test)

**Visual inspection:**

1. Inspect every pouch for (15 min):
  - Seal integrity (no leaks, no delamination)
  - Surface damage (punctures, tears)
  - Deformation (excessive swelling, vacuum collapse)

2. Set aside any questionable pouches for detailed inspection

**Weight verification:**

3. Randomly select **10 pouches per batch**
4. Weigh each pouch on calibrated scale (NOT tared, measuring total packaged weight) (10 min)
5. **QC Target:  $105.5 \text{ g} \pm 0.5 \text{ g}$  total packaged weight**
  - This is:  $\sim 101\text{--}102 \text{ g}$  food +  $4.5 \text{ g}$  pouch
6. Record all 10 weights on QC log
7. **Pass criteria: At least 9 out of 10 within specification**
8. **If >1 pouch fails: Inspect additional 20 pouches or reject batch**

**Destructive testing (1 pouch per batch):**

9. Select one pouch from middle of batch
10. Open carefully and evaluate (10min):
  - **Custard texture:** Firm, holds shape, sliceable (NOT liquid, NOT rubbery)
  - **Protein set:** Egg whites should create cohesive custard-like structure
  - **Syneresis:** <5% free liquid on surface (minor weeping acceptable)
  - **Odor:** Neutral to meaty, NO sour, rancid, or off-odors
  - **Color:** Consistent tan/beige (from powder), uniform throughout
  - **Texture when sliced:** Should cut cleanly, not crumble or ooze
11. Record all observations with photos if needed
12. **Obtain QC sign-off on destructive test results**

**Final steps:**

13. Label all passed pouches with (20 min):
  - Batch number
  - Production date
  - Best-by date (18 months from production)
  - SKU code: DogCore (ORANGE band/label)
14. Store at  **$20 \pm 2 \text{ deg C}$ ,  $\text{RH} < 60\%$**
15. **Retain 5 pouches per batch** for:
  - Stability testing (shelf-life validation)
  - Regulatory samples (if required)
  - Customer complaint investigation (if needed)
16. Complete all production logs and submit to QC for filing (5 min)


**QC Checkpoints:**

- Visual inspection results recorded (pass/fail for each pouch)
- Weight verification: 10 weights recorded, pass criteria met ( $105.5 \text{ g} \pm 0.5 \text{ g}$ )
- Destructive test: photos attached, custard texture confirmed
- All parameters within spec (texture, odor, color, protein set)
- Labeling complete and verified (ORANGE band for DogCore)
- 5 retention samples properly stored and logged

**DogCore-Specific Quality Criteria:**

- **Expected texture:** Firm custard (similar to baked egg custard or flan)
- **Protein gelation:** Should be evident - product holds shape when inverted
- **NOT acceptable:** Liquid/runny texture (indicates protein did not set)
- **NOT acceptable:** Rubbery/tough texture (indicates over-processing or too much protein)
- **Acceptable variation:** Slight firmness differences batch-to-batch (egg white gelation varies slightly)



**Production Flow Diagram - DogCore**

## Production Timeline Summary - DogCore

Table 9.3: Complete DogCore Production Timeline for 100-Pouch Batch

| Step   | Activity                 | Time (min)                   | Personnel  | Can Parallel?         |
|--|--------------------------|------------------------------|------------|-----------------------|
| <i>Pre-Production</i>                            | Broth rendering          | 720                          | 1          | N/A (overnight)       |
| 1  | Liquid phase prep        | 35-40                        | 1          | No                    |
| 2  | DogPro premix addition   | 10-12                        | 1          | No                    |
| 3  | Powder preparation       | 10-15                        | 1          | Yes (during Step 1-2) |
| 4  | Vortex mixing (CRITICAL) | 25-30                        | 2          | No                    |
| 5  | Pouch filling            | 50-60                        | 1-2        | No                    |
| 6  | Seal & retort            | 120                          | 2          | Mostly waiting        |
| 7  | Post-retort QC           | 60                           | 2          | No                    |
| <b>TOTAL PRODUCTION TIME<br/>(Approximately)</b> |                          | <b>310-347<br/>5-6 hours</b> | <b>2-3</b> |                       |

### Key Differences from CatCore Timeline:

- **FASTER:** No blanching (saves 35-40 min)
- **FASTER:** No gel preparation/injection (saves 30-35 min)
- **FASTER:** No marination wait (saves 30 min)
- **SLOWER:** Vortex mixing requires careful attention (25-30 min)
- **NET RESULT:** DogCore is approximately 1-1.5 hours FASTER than CatCore

### Notes on Timeline Optimization:

- Step 3 (powder prep) can be done in parallel with Steps 1-2 if 2 operators available
- Step 4 (vortex mixing) is CRITICAL and cannot be rushed - quality depends on slow powder addition
- Step 6 retort cycle is mostly waiting time; operators can begin cleaning and prep for next batch
- With experienced operators and optimized workflow, total production time approaches 5 hours
- First production run may take longer (6-6.5 hours) as operators familiarize with vortex mixing technique

## Critical Control Points (CCP) Summary - DogCore

### Corrective Actions:

- If any CCP is outside critical limits, STOP production immediately
- Notify Line Supervisor and QC Manager
- Identify root cause before resuming
- Affected product must be segregated and evaluated for:
  - Rework (if safe and feasible - e.g., if slurry too thick, add broth and remix)
  - Downgrade (if food safety maintained but quality affected)
  - Discard (if food safety cannot be assured or texture completely wrong)
- Document all deviations and corrective actions in batch log
- Obtain QC Manager sign-off before resuming production



## **Troubleshooting Guide - DogCore Specific**

Table 9.4: HACCP Critical Control Points for DogCore Retort Process

| <b>CCP</b>                       | <b>Hazard</b>   | <b>Critical Limit</b>  | <b>Monitoring</b>                                 |
|----------------------------------|---|--|---|
| Broth pH                         | Bacterial growth                                      | pH 6.4-6.5   | Calibrated pH meter<br>(Step 1 & 2)               |
| Palatant-Antioxidant<br>Addition | Lipid oxidation<br>Vitamin E deficiency               | 100 ml per batch<br>BLUE sticker (variant A)                           | Visual verification<br>Supervisor sign-off        |
| DogPro Premix<br>Addition        | Micronutrient<br>deficiency                           | 100 g per batch<br>ORANGE sticker                                      | Weight verification<br>Color code check           |
| DogCore Powder<br>Addition       | Micronutrient<br>deficiency<br>Moisture contamination | 6.50 kg per batch<br>GREEN sticker<br>Dry, free-flowing                | Weight verification<br>Visual/odor check          |
| Vortex Mixing                    | Pizza dough formation<br>Uneven dispersion            | Custard-like slurry<br>Pourable consistency<br>20-25 min addition time | Visual check<br>Pour test<br>Timer                |
| Fill Weight                      | Under/over filling<br>Nutritional imbalance           | 112.5 +/- 0.5 g  | Scale check every<br>10th pouch                   |
| Seal Integrity                   | Contamination<br>Spoilage                             | No wrinkles, complete<br>edges, 2 bands                                | 100 percent visual<br>inspection                  |
| Retort Temperature               | Pathogen survival<br>( <i>C. botulinum</i> )          | 121 deg C, 45 min<br>F-value $\geq 12$<br>Never $< 118$ deg C          | Continuous chart<br>recorder<br>Temperature probe |
| Protein Gelation                 | Quality defect<br>Poor texture                        | Firm custard texture<br>Not liquid, not rubbery                        | Destructive test<br>(1 pouch per batch)           |
| Cooling Time                     | Spore outgrowth                                       | $< 40$ deg C within 20 min   | Calibrated thermometer                            |
| Final Weight                     | Moisture loss<br>Quality control                      | 105.5 +/- 0.5 g total<br>(food + pouch)                                | 10 random pouches<br>per batch                    |

Table 9.5: Common DogCore Issues and Solutions

| <b>Issue</b>                      | <b>Likely Cause</b>  | <b>Solution</b>   |
|-----------------------------------|--|---|
| Powder clumping during storage    | Moisture absorption  | Store in sealed container with desiccant. Sieve before use if clumped.                                |
| Pizza dough texture during mixing | Powder added too fast, insufficient vortex                     | STOP. Add 200-300 ml warm broth. Remix slowly. Resume powder addition at half speed.                  |
| Slurry too thin (watery)          | Too much broth, powder underweight                             | Check powder weight. If correct, continue - may still set during retort. Test one pouch first.        |
| Slurry too thick (paste-like)     | Powder overweight, broth underweight, powder absorbed moisture | Add 100-200 ml warm broth incrementally until pourable. Record adjustment in log.                     |
| Powder not dispersing (floating)  | Vortex too weak, powder added too close to surface             | Increase mixer speed. Add powder closer to vortex center. Slow addition rate.                         |
| Dry powder pockets in slurry      | Incomplete mixing, powder dumped instead of streamed           | Continue mixing for 5-10 min. Break up pockets manually if needed. Do NOT proceed to filling.         |
| Slurry separating (liquid on top) | Inadequate mixing time, powder settling                        | Remix for 2-3 min before filling. Stir gently every 10 pouches during filling.                        |
| Post-retort too liquid            | Insufficient protein, retort cycle incomplete                  | Check powder weight (should be 6.50 kg). Verify retort F-value achieved. Reject batch if liquid.      |
| Post-retort too rubbery           | Excessive protein, over-retorting                              | Check powder weight. Verify retort cycle (45 min only). Minor rubberiness acceptable.                 |
| Post-retort syneresis >5 percent  | Insufficient protein binding, pH imbalance                     | Check pH (should be 6.4-6.5). Minor syneresis acceptable. If >10 percent, investigate powder quality. |
| Seal failures on DogCore pouches  | Thick slurry contaminating seal area                           | Wipe pouch rim before sealing. Ensure slurry below fill line. Increase seal temperature by 5 deg C.   |
| Batch weight significant          | Measurement error  | Reweigh all components be-  |

**Batch Record Template - DogCore****Production Date:** \_\_\_\_\_ **Batch Number:** \_\_\_\_\_**SKU:** DogCore **Target Quantity:** 100 pouches**Line Supervisor:** \_\_\_\_\_ **QC Inspector:** \_\_\_\_\_**Step 1: Liquid Phase Preparation**

Bone broth weight: \_\_\_\_\_ kg Target: 4.60 kg  
 pH (25 deg C): \_\_\_\_\_ Target: 6.4-6.5 QC Sign: \_\_\_\_\_

Palatant type: A (BLUE) 100 ml added Supervisor Sign: \_\_\_\_\_

Final temp (40 deg C): \_\_\_\_\_ Enriched broth: \_\_\_\_\_ kg  
 deg C (target: 4.70)

**Step 2: DogPro Premix Addition**

Premix sticker: ORANGE (Dog- Verified: \_\_\_\_\_ Supervisor Sign: \_\_\_\_\_  
 Pro)

Premix weight: \_\_\_\_\_ g Target: 100 g  
 pH (after premix): \_\_\_\_\_ Target: 6.4-6.5 QC Sign: \_\_\_\_\_

DogPro-enriched broth: \_\_\_\_\_ kg Target: 4.80 kg

**Step 3: DogCore Powder Preparation**

Powder sticker: GREEN (Dog- Verified: \_\_\_\_\_ Supervisor Sign: \_\_\_\_\_  
 Core)

Powder weight: \_\_\_\_\_ kg Target: 6.50 kg

Visual check: Pass Fail Color: \_\_\_\_\_

Odor check: Pass Fail Notes: \_\_\_\_\_

Sieving needed: Yes No

**Step 4: Vortex Mixing**

Mixing start time: \_\_\_\_\_ Vortex established: \_\_\_\_\_

Powder addition start: \_\_\_\_\_ Addition end: \_\_\_\_\_ Duration: \_\_\_\_\_ min

Target addition time: 20-25 min Actual: \_\_\_\_\_ min

Final slurry weight: \_\_\_\_\_ kg Target: 11.30 kg

Consistency check: \_\_\_\_\_ Custard-like Pour test: Pass  
Too thick Too thin Fail

Temperature: \_\_\_\_\_ deg C Target: 35-40 deg C

Issues encountered: \_\_\_\_\_

**Step 5: Pouch Filling (every 10th pouch)**

Pouch #: 10 20 30 40 50 60 70 80 90 100

Weight (g): \_\_\_\_\_

Target: 112-113 g (scale tared) Operator Sign: \_\_\_\_\_

**Step 6: Seal & Retort**

Sealing complete: \_\_\_\_\_ Rejected pouches: \_\_\_\_\_

Retort load time: \_\_\_\_\_ Retort start: \_\_\_\_\_

Come-up time: \_\_\_\_\_ Target:  $\leq 10$  min  
min

Hold temp: \_\_\_\_\_ Target: 121 deg C  
deg C

Hold time: \_\_\_\_\_ Target: 45 min  
min

F-value: \_\_\_\_\_ Target:  $\geq 12$

Cooling end: \_\_\_\_\_ Temp: \_\_\_\_\_  
deg C (target:  $< 40$  deg C)

Chart attached: Yes Supervisor Sign: QC Sign: \_\_\_\_\_

**Step 7: Post-Retort QC**

Visual inspection: Pouches rejected: \_\_\_\_\_ Reason: \_\_\_\_\_

Weight verification (10 random pouches):

Pouch #: \_\_\_\_\_

Weight (g): \_\_\_\_\_

Target: 105.5 +/- 0.5 g Pass:  $\geq 9/10$  within spec Result: Pass Fail

*Destructive test (1 pouch):*

|                   |      |          |          |        |
|-------------------|------|----------|----------|--------|
| Custard texture:  | Firm | Too soft | Too hard | Notes: |
| Protein gelation: | Pass | Fail     |          | Notes: |
| Syneresis:        | <5%: | Yes      | No       | Notes: |
| Odor:             | Pass | Fail     |          | Notes: |
| Color:            | Pass | Fail     |          | Notes: |
| Sliceability:     | Pass | Fail     |          | Notes: |
| Photos attached:  | Yes  |          | QC       | Sign:  |

**Final Disposition:**

|                    |  |           |
|--------------------|--|-----------|
| Pouches approved:  | _____ / 100                              |           |
| Pouches rejected:  | _____ / 100                              | Reason:   |
| Retention samples: | 5 pouches stored                         | Location: |
| Batch status:      | APPROVED REJECTED HOLD FOR INVESTIGATION |           |

**Final Sign-Offs:**

|                  |       |       |       |
|------------------|-------|-------|-------|
| Line Supervisor: | _____ | Date: | _____ |
| QC Manager:      | _____ | Date: | _____ |

## Notes

- This SOP covers DogCore powder-based production flow only
- For CatCore (alginate gel system), refer to SOP 30
- Detailed QC sampling plans (ICP assays, vitamin assays, microbiological testing): See detailed SOP binder
- Tolerance specifications and deviation handling procedures: See detailed SOP binder
- Equipment calibration schedules and maintenance logs: See equipment maintenance records
- All logs and sign-offs must be preserved per HACCP requirements for minimum 2 years
- For pre-pilot kitchen test protocols and validation studies: See separate validation documents
- Emergency contact information and escalation procedures: See safety manual

## Key Differences from CatCore SOP 30:

- DogCore starts with 4.60 kg broth (vs 4.10 kg in CatCore)
- NO blanching step (powder is pre-processed)
- NO two-broth split (single unified system)
- NO alginate gel system (custard texture from egg white gelation)
- CRITICAL vortex mixing step (prevents pizza dough formation)
- Single-phase fill at 112.5 g
- Approximately 1-1.5 hours FASTER than CatCore (5-6 hours vs 7-8 hours)
- Post-retort texture is custard-like (vs gel-like in CatCore)

## Revision History:

- Rev H.3.1.0 (21 October 2025): Initial DogCore powder-based SOP, forked from CatCore SOP 30, adapted for vortex mixing system and custard texture profile

## Document Control:

- Document Owner: Growlrr Foods Pvt Ltd, Quality Assurance Department
- Review Frequency: Quarterly or after any significant process change
- Next Review Date: 21 January 2026
- Distribution: Line Supervisors, QC Managers, Production Operators
- Controlled Copy: This is a controlled document. Do not copy without authorization.

## Broth Base pH Adjustment SOP – Pre-Heating Step (3.0 kg batch)

**Scope:** pH adjustment of a 3.0 kg broth aliquot after weighing and prior to heating to 60°C. Target pH: **6.4–6.5** at 25°C.

## Approved reagents

- Citric acid monohydrate, food-grade – prepare **10% w/v** solution (10 g / 100 mL) – “Citric 10%”.
- Sodium citrate dihydrate, food-grade – prepare **10% w/v** solution (10 g / 100 mL) – “Sodium Citrate 10%”.
- Potassium bicarbonate, food-grade – prepare **5% w/v** solution (5 g / 100 mL) – “K-Bicarb 5%” (alternative to sodium citrate).

## Equipment & PPE

Calibrated pH meter (25°C calibration), magnetic or overhead stirrer, 10 mL and 1 mL pipettes/syringes, gloves, goggles, lab coat.

## Procedure

1. **Calibrate** pH meter at pH 7.00 and pH 4.00 at 25°C. Document on Form MAT-01A.
2. Place the 3.0 kg broth in mixing vessel; equilibrate to 25°C.
3. Measure and record initial pH: **pH<sub>0</sub>**.
4. If **pH<sub>0</sub>** is within 6.4–6.5: proceed to premix addition and sign MAT-01A.
5. If **pH<sub>0</sub> > 6.5**: add **Citric 10%** in **1.0 mL** increments:
  - Add 1.0 mL, mix 60 s, measure pH, record.
  - Repeat until pH ∈ [6.4,6.5].
  - Control limit: if cumulative addition > 10 mL without reaching target, stop and call Floor Chemist; document deviation.
6. If **pH<sub>0</sub> < 6.4**: add **Sodium Citrate 10%** (or **K-Bicarb 5%**) in **1.0 mL** increments:
  - Add 1.0 mL, mix 60 s, measure pH, record.
  - Repeat until pH ∈ [6.4,6.5].
  - Control limit: if cumulative addition > 10 mL without reaching target, stop and call Floor Chemist; document deviation.
7. Once target achieved, record final pH: **pH<sub>f</sub>**, total reagent added, time, operator initials on Form MAT-01A. Only then add Chelator Premix.

## Notes

- 1 mL of a 10% solution = 0.10 g reagent; for 3.0 kg broth this is a small incremental change ( 0.0033% w/w), facilitating precise control.
- Do not measure pH at 60°C for QC decisions; measure at 25°C.
- If unusually large reagent volume is required, document and halt for technical review – buffer capacity may indicate upstream raw variation.

**Form MAT-01A (Broth Base pH Log):** Attach to batch record.

**Operator:** \_\_\_\_\_ **Date/Time:** \_\_\_\_\_

## SOP: Bone Broth Rendering and Skeletal Mince Preparation for Catpro SKU

### 1. Chicken Frame Line

**Objective:** Produce standardized calcium- and collagen-bearing broth and skeletal mince for chicken meat SKUs.

1. **Step 1 - Input Materials:**
2. Total Time needed 10-15 min
  - Log start time in timesheet.
  - 2.5 kg cleaned chicken skeletal frames with 30% chicken neck and de-clawed feet. Use high velocity hot jet spray to clean off grit.



- 8—10 kg potable water depending on surface area of kettle. Target 4.10Kg rendered bone broth
- 0.2 % acetic acid (2 mL/L water)
- Log end time in timesheet

3. **Step 2- Rendering:**

4. Total Time needed 12-13 hours with 12 hours of continuous broth rendering time.

- (a) Log start time in timesheet. Ensure no more than 10 minutes have passed between end time of Step 1 and start time of Step 2 .
- (b) Charge kettle with water and acetic acid; add frames (1:4 w/v ratio) or as per SOP.
- (c) Maintain simmer at 90–95 °C for 12 h; compensate evaporation if needed.
- (d) Skim fats and solids every 2 h.
- (e) Reduce to approximately 4.50 kg $\pm$  0.4kg finished broth.
- (f) Strain through 1 mm mesh;
- (g) Label with date, time and batch number. Refrigerate the broth and use within 12 hours.
- (h) Retain cooked bones and soft matrix for mincing. Refrigerate if needed and use within 12 hours. Label with date, time and batch number.
- (i) Log end time in timesheet. Maintain coldchain logs. Use within 12 hours if refrigerated or immediately if in process.

5. **Step 3 - Bone Residue Handling and Frame Mince Production:**

6. Total Time needed 30-40 min

- (a) Log start time in timesheet.
- (b) Rinse cooked bone residue with warm potable water to remove surface grit and fines.
- (c) Remove any dense cortical fragments (>10 mm).
- (d) Pass residue twice through 0.3 mm grinding plate; sieve twice through 0.5 mm mesh.
- (e) Collect fine mince (target yield  $\approx$ 1.65 kg) for 10kg production run.
- (f) Store  $\leq$ 4 °C or freeze at -18 °C until use. Label with date, time and batch number.
- (g) Log end time in timesheet. Maintain coldchain logs. Use within 12 hours if refrigerated or immediately if in process.

## 2. Goat Frame Line

**Objective:** Produce lamb skeletal broth and mince with inherent calcium and collagen content for goat meat SKUs.

1. **Step 1 - Input Materials:**

2. Total Time needed 10-15 min

- Log start time in timesheet.
- 3.0 kg goat skeletal frames with 30% cleaned, skined, de-hooved goat trotters. Use high velocity hot jet spray to clean off grit.
- 8—10 kg potable water depending on surface area of kettle. Target 4.10Kg rendered bone broth
- 0.2 % acetic acid (2 mL/L water)
- Log end time in timesheet

3. **Step 2 - Rendering:**

4. Total Time needed 12-13 hours with 12 hours of continuous broth rendering time.

- (a) Log start time in timesheet. Ensure no more than 10 minutes have passed between end time of Step 1 and start time of Step 2 .
- (b) Charge kettle with water and acetic acid; add bones (1:4 w/v ratio) or as per SOP.
- (c) Simmer 12 h at 90–95 °C; allow slow evaporation to 4.50 kg  $\pm$  0.4kg broth.
- (d) Skim surface fats periodically; strain twice through 1 mm mesh .
- (e) Label with date, time and batch number. Refrigerate the broth and use within 12 hours.

- (f) Retain cooked bones and soft matrix for mincing. Refriderate if needed and use within 12 hours. Lable with date, time and batch number.
- (g) Log end time in timesheet. Maintain coldchain logs. Use within 12 hours if refridgerated or immediately if in process.

5. **Step 3- Bone Residue Handling and Frame Mince Production:**

6. Total Time needed 30-40 min
- (a) Log start time in timesheet.
  - (b) Rinse residue; discard sharp or metallic fragments.
  - (c) Double-grind through 0.3 mm plate; sieve twice through 0.5 mm mesh.
  - (d) Target yield  $\approx$ 2.20 kg fine mince.
  - (e) Store at  $\leq 4^{\circ}\text{C}$  or frozen ( $-18^{\circ}\text{C}$ ). Lable with date, time and batch number.
  - (f) Log end time in timesheet. Maintain coldchain logs. Use within 12 hours if refridgerated or immediately if in process.

**3. QC and Verification**

- Composite samples (100 g) from each batch to undergo Ca and P assay (ICP or pooled lab test).
- Target calcium 400—800 mg/100 g; phosphorus 300–400 mg/100 g.
- Record batch lot numbers; link broth and mince to QC log.

**Bill of Materials: CatCore Heart SKU**

**Batch Specifications**

- Batch size: 10 kg (100 pouches)
- Per pouch declared weight: 100 g

**Raw Ingredients**

Table 9.6: CatCore Heart (Chicken) SKU - Raw Materials per 10 kg Batch

| Ingredient          | Per Batch (Kg)                     | Prep Method           | Traceability Log |                         |
|---------------------|------------------------------------|-----------------------|------------------|-------------------------|
| Chicken heart       | $2.400 \pm 0.08$                   | Diced 1.5cm           | [QC-FORM-_____]  |                         |
| Chicken frame mince | $2.000 \pm 0.05$                   | Fine grind 5mm sieve  | [QC-FORM-_____]  | Follow Bone Broth SOP 3 |
| Chicken muscle cuts | $1.100 \pm 0.08$                   | Diced 1.5cm           | [QC-FORM-_____]  |                         |
| Pumpkin puree       | $0.400 \pm 0.01$                   | Blended with egg yolk | [QC-FORM-_____]  | Pre-cooked a            |
| Egg yolk powder     | $0.400 \pm 0.01$                   | Blended with pumpkin  | [QC-FORM-_____]  | Blenc                   |
| Chicken liver       | $0.200 \pm 0.005$                  | Diced 1.5cm           | [QC-FORM-_____]  | Ren                     |
| <b>TOTAL SOLIDS</b> | <b><math>6.500 \pm 0.05</math></b> | Caliburated Scale     | [QC-FORM-_____]  | Refridgerate            |

**Processing Instructions**

Thoroughly wash all meat products in running hot jet stream water for 5 minutes to wash off any blood, coagulants, debris and other undesirable particles. **Solid Preparation (1.5cm Standard):**